

# Renault / ASM-X 10.1.9

## Legend

Existing Function

Currently Under Development

Functionality doesn't apply

ABS / ABR				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.0 V3 (MEGANE II)				
Special Functions				
After-Sales Operation Date				
Speedo Index				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.0 V4-23-0F				
Special Functions				
Bleed Hydraulic Unit And Braking Circuits				
Speedo Index				
Veh. Speed At Initialisation				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.0 x06/65/76 v2				
Special Functions				
Speedo Index				
Vehicle Parameter				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.0 X85 VDIAG 15 (CLIO III)				
Special Functions				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Veh. Speed At Initialisation				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.0-2.3-14				
Special Functions				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.1 L35 VDIAG 18-0000-18				
Special Functions				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABS 8.1 X61-9669-15				
Special Functions				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Vehicle Parameters				

Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS 8.1 X90 VDIAG 18 B2-0000-18	✓	✓	✓	✓
<i>Special Functions</i>				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS 8.1 X90 VDIAG 1C-0000-1C	✓	✓	✓	✓
<i>Special Functions</i>				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS BOSCH 5.3 (2XX.5)	✓	✓	✓	✓
<i>Special Functions</i>				
Speed Index Programming				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS BOSCH 8.0	✓	✓	✓	✓
<i>Special Functions</i>				
Bleed Hydraulic Unit And Braking Circuits				
PostSale Repair Date Modification				
Speedo Index				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS BOSCH 8.0 (MODUS)	✓	✓	✓	✓
<i>Special Functions</i>				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS EA111 EA106 H79-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS EBC 430 TRW	✓	✓	✓	✓
<i>Special Functions</i>				
PostSale Repair Date Modification				
Speedo Index				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS EBC 430 TRW X70 Ph3-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
Speedo Index				
Write Date Of Last After Sales Operation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS EBC 430 TRW X83Ph2-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
Speedo Index				
System Purge				
Write Date Of Last After Sales Operation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS ESP D66 Bosch_5.7	✓	✓	👤	👤
ABS ESP-0000-10	✓	✓	✓	✓
<i>Special Functions</i>				

Auto Stop Lights Illumination Authorisation				
Brake Pressure Offset Sensor				
Chassis Wear Programming				
GearBox Type				
Hydraulic Brake Compensation				
PostSale Repair Date Modification				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Steering Wheel Angle Offset Sensor				
Transverse Acceleration Offset Sensor				
Vehicle Parameters				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS ESPX70ph3-4146-09	✓	✓	✓	✓
<b>Special Functions</b>				
Brake system prime				
Engine Type				
Gearbox type				
Speedo Index				
Steering Wheel Angle Sensor				
Suspension type of film				
Vehicle Parameters				
Vehicle Type				
Write Date Of Last After Sales Operation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS MK60 x74	✓	✓	✓	✓
<b>Special Functions</b>				
ABS / ESP Calibration Programming				
Braking Definition				
Engine Torque Index				
GearBox Type				
PostSale Repair Date Modification				
Speedo Index				
Vehicle Parameter				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS TEVES 30X5	✓	✓	⊘	⊘
ABS TEVES 3XX5	✓	✓	✓	✓
<b>Special Functions</b>				
Speed Index				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS X44 MK70 -0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Check Target Teeth				
Gearbox Type				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS_ABS_H45-0000-04	✓	✓	✓	⊘
ABS_ESPX84_0023_08_A	✓	✓	✓	✓
<b>Special Functions</b>				
Auto Stop Lights Illumination Authorisation				
Bleed Hydraulic Unit And Braking Circuits				
ESP automatic reconnection threshold				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS_ESPX84_0023_0A_A	✓	✓	✓	✓
<b>Special Functions</b>				
Auto Stop Lights Illumination Authorisation				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				

Esp Automatic Reconnection Threshold				
Esp Sensor Programming				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS_X91-0000-08	✓	✓	✓	✓
Special Functions				
Check Target Teeth				
Gearbox type				
Speedo Index				
Type Parking Brake				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS_X95-0000-08	✓	✓	✓	✓
Special Functions				
Front Left Wheel				
Front Right Wheel				
Gearbox type				
Rear Left Wheel				
Rear Right Wheel				
Speedo Index				
Type Parking Brake				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ABS-0020-14	✓	✓	✓	✓
Special Functions				
Check Target Teeth				
Gearbox Type				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP 8.0 V5-23-0B	✓	✓	✓	✓
Special Functions				
Auto Stop Lights Illumination Authorisation				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Esp Automatic Reconnection Threshold				
Esp Sensor Programming				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Vehicle Parameters				
Vehicle Speed on the Initialisation				
Write Date Of Last After Sales Operation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP 8.1 X44-EC8D-05	✓	✓	✓	✓
Special Functions				
Auto Stop Lights Illumination Authorisation				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Offsets Sensors				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Steering Wheel Angle Sensor				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP 8.1 X61-966B-0F	✓	✓	✓	✓
Special Functions				

Auto Stop Lights Illumination Authorisation				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Esp Automatic Reconnection Threshold				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP EV1011 H79-0000-08	✓	✓	✓	✓
<b>Special Functions</b>				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Offsets Sensors				
Speedo Index				
Vehicle Parameters				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP MK60 x74	✓	✓	✓	✓
<b>Special Functions</b>				
ABS / ESP Calibration Programming				
Braking Definition				
GearBox Type				
PostSale Repair Date Modification				
Remote Control Cruise Control				
Speed Index				
Steering Wheel Angle Sensor				
Vehicle Parameter				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP X65 PSP_Bosch_5.7	✓	✓	✓	✓
<b>Special Functions</b>				
Speedo Index				
Steering wheel angle sensor				
Vehicle Parameters				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP X84 RS-6FAF-11	👤	✓	✓	✓
<b>Special Functions</b>				
Auto Stop Lights Illumination Authorisation				
Bleed Hydraulic Unit And Braking Circuits				
Check Target Teeth				
Esp Sensor Programming				
Prevention Of Stop Light Auto Illumination				
Speedo Index				
Vehicle Parameters				
Vehicle Speed on the Initialisation				
Write Date Of Last After Sales Operation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP_X91-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Brake Pressure Offset Sensor				
Check Target Teeth				
Gearbox type				
Speedo Index				
Steering Wheel Angle Offset Sensor				
Transverse Acceleration Offset Sensor				
Type Parking Brake				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ESP_X95-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Brake Pressure Offset Sensor				
Check Target Teeth				

Gearbox type
Speedo Index
Steering Wheel Angle Offset Sensor
Transverse Acceleration Offset Sensor
Type Parking Brake
Write Date Of Last After Sales Operation
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ESP-0000-11	✓	✓	✓	✓

Special Functions
Auto Stop Lights Illumination Authorisation
Brake Pressure Offset Sensor
Chassis Wear Programming
Check Target Teeth
Gearbox type
Hydraulic Brake Compensation
Prevention Of Stop Light Auto Illumination
Speedo Index
Steering Wheel Angle Offset Sensor
Transverse Acceleration Offset Sensor
Vehicle Parameters
Write Date Of Last After Sales Operation
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ESP-0020-11	✓	✓	✓	✓

Special Functions
Auto Stop Lights Illumination Authorisation
Brake Pressure Offset Sensor
Chassis Wear Programming
Check Target Teeth
Gearbox type
Hydraulic Brake Compensation
Prevention Of Stop Light Auto Illumination
Speedo Index
Steering Wheel Angle Offset Sensor
Transverse Acceleration Offset Sensor
Vehicle Parameters
Write Date Of Last After Sales Operation
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ESP-F.08-08	✓	✓	✓	✓

Special Functions
Abs/Esp Calibration
Check Target Teeth
Gearbox Type
Pressure Sensor
Speedo Index
Steering wheel angle sensor
Transverse Acceleration Sensor
Vehicle Parameters
Write Date Of Last After Sales Operation
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
VDC_ABS_H45-03-04	✓	✓	✓	⊘
VSU_X61-0300-04	✓	✓	✓	✓

Special Functions
Check Target Teeth
Speedo Index
Write Date Of Last After Sales Operation
Write Vin

**ADDITIONAL HEATING CITROEN**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ADD HEATER_X74_X73	✓	✓	✓	✓

Special Functions
Erase Incorrect Cranking Counter
Erase Overheating Counter

**AIRBAG (SRS)**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG ACU3MK2 X70Ph3-000F-08	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Configuration Of System Components</i>				
<i>ECU Status</i>				
<i>Ignition Module Configuration</i>				
<i>Unlock Computer</i>				
<i>Write Date Of Last After Sales Operation</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG ACU3MK3 X83Ph2-000F-30	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Driver's Front Airbag</i>				
<i>Driver's Pretensioner</i>				
<i>Front passenger seat. 2 seating capacity</i>				
<i>Front Passenger(S) Pretensioner(S)</i>				
<i>Front thorax side air bag, driver side</i>				
<i>Front thorax side air bag, passenger side</i>				
<i>Left-Hand Curtain Airbag</i>				
<i>Lock Computer</i>				
<i>Lock Passenger's Airbag With Key</i>				
<i>Passenger's Front Airbag</i>				
<i>Pretensioner row 1 left-hand side</i>				
<i>Pretensioner row 1 right-hand side</i>				
<i>Pretensioner row 2 left-hand side</i>				
<i>Pretensioner row 2 right-hand side</i>				
<i>Rear left-hand head-level side airbag</i>				
<i>Rear right-hand head-level side airbag</i>				
<i>Right-Hand Curtain Airbag</i>				
<i>Side On Which Steering Wheel Fitted</i>				
<i>Unlock Computer</i>				
<i>Vehicle Type</i>				
<i>Write Date Of Last After Sales Operation</i>				
<i>Write Vin</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG ACU3MK3 X83Ph2-000F-38 (Traffic II Ph2)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Driver's Front Airbag</i>				
<i>Driver's pretensioner</i>				
<i>Front passenger seat. 2 seating capacity</i>				
<i>Front Passenger(S) Pretensioner(S)</i>				
<i>Front thorax side air bag, driver side</i>				
<i>Front thorax side air bag, passenger side</i>				
<i>Left-Hand Curtain Airbag</i>				
<i>Lock Passenger's Airbag With Key</i>				
<i>Locking of the ECU</i>				
<i>Passenger's Front Airbag</i>				
<i>Pretensioner row 1 left-hand side</i>				
<i>Pretensioner row 1 right-hand side</i>				
<i>Pretensioner row 2 left-hand side</i>				
<i>Pretensioner row 2 right-hand side</i>				
<i>Rear left-hand head-level side airbag</i>				
<i>Rear right-hand head-level side airbag</i>				
<i>Right-Hand Curtain Airbag</i>				
<i>Side On Which Steering Wheel Fitted</i>				
<i>Unlock Computer</i>				
<i>Vehicle Type</i>				
<i>Write Date Of Last After Sales Operation</i>				
<i>Write Vin</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG TEMIC H79 50VOIES-0000-18	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Driver's Front Airbag</i>				
<i>Driver's Front Side Impact Sensor</i>				
<i>Driver's Seat Buckle Sensor</i>				
<i>Driver's Side Thorax Lateral Airbag</i>				
<i>ECU locking</i>				
<i>Front Driver Inertia Reel</i>				

Front Passenger Inertia Reel
Impact information connection
Pass Airbag Deactivation Warning Light
Passenger Airbag Locking Mode
Passenger Presence Detection Sensor
Passenger's Front Airbag
Passenger's Front Side Impact Sensor
Passenger's Seat Buckle Sensor
Passenger's Side Thorax Lateral Airbag
Reading Impact Contexts
Seat Belt Light
Seat Belt Reminder Buzzer
Side On Which Steering Wheel Fitted
Unlock Computer
Vehicle Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG X61 -0401-04	✓	✓	✓	✓

Special Functions
Air Bag Fault Warning Light
Computer Locked By Tool
Computer Must Be Replaced
Diagnosticable ECUs
Driver's Front Airbag
Driver's Front Airbag Circuit 1
Driver's Seat Buckle Sensor
ECU locking
ECUs Present
Fault/S Memorised
Front Left-Hand Chest-Level Side Airbag
Front Right-Hand Chest-Level Side Airbag
Left-Hand Curtain Airbag
Left-Hand Side Impact Sensor
Locking Supply Diag Outside Limits
Passenger Air Bag Locking Mode
Passenger Air Bag Status Light
Passenger Front Air Bag Circuit 1
Passenger's Air Bag Locked
Passenger's Airbag Disable Mode
Passenger's Front Airbag
Pre-tensioning seat belt front LH
Pre-tensioning seat belt front RH
Rear Left-Hand Inertia Wheel
Rear Right-Hand Inertia Reel
Right-Hand Curtain Airbag
Right-Hand Side Impact Sensor
Side On Which Steering Wheel Fitted
Unlock Computer
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG X91-0000-04	✓	✓	⊘	✓

Special Functions
ECU locking
Passenger Airbag Locking Mode
Reading Impact Contexts
Side On Which Steering Wheel Fitted
Unlock Computer
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG X95-0000-04	✓	✓	⊘	✓

Special Functions
Lock Computer
Reading Impact Contexts
Side On Which Steering Wheel Fitted
Unlock Computer
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG_RC5_P1_P2_X84-0-14	✓	✓	⊘	✓

<b>Special Functions</b>
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver Side Loop Pretensioners
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Lap Strap/Seat Airbag
Driver's Seat Buckle Sensor
Driver's Seat Position Sensor
Driver's Side Rear Inertia Reel
Driver's Side Sensor
Front thorax side air bag, driver side
Front thorax side air bag, passenger side
Lock Computer
Passenger Front Air Bag Circuit 1
Passenger Side Loop Pretensioners
Passenger's Frontal Airbag Circuit 2
Passenger's Lap Strap/Seat Airbag
Passenger's Side Rear Inertia Reel
Passenger's Side Sensor
Read Configuration: Locking Switch
Reading Impact Contexts
Rear Driver's Side Thorax Lateral Airbag
Rear Passenger Side Thorax Lateral Airbag
Side On Which Steering Wheel Fitted
Unlock Computer
Vehicle Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ABG_RC5_P1_P2_X85-0-14	✓	✓	⊘	✓

<b>Special Functions</b>
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Lap Strap/Seat Airbag
Driver's Seat Buckle Sensor
Driver's Seat Position Sensor
Driver's Side Rear Reel
Driver's Side Sensor
Driver's Side Thorax Lateral Airbag
ECU Status
Front Driver Inertia Reel
Front Passenger Inertia Reel
Lock Switch
Passenger Front Air Bag Circuit 1
Passenger's Frontal Airbag Circuit 2
Passenger's Lap Strap/Seat Airbag
Passenger's Side Rear Reel
Passenger's Side Thorax Lateral Airbag
Rear Driver's Side Thorax Lateral Airbag
Rear Passenger Side Thorax Lateral Airbag
Side On Which Steering Wheel Fitted
Side Passenger Sensor
Unlock Computer
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ACU3_Renault X83 vdiag38 (Traffic II)	✓	✓	⊘	✓

<b>Special Functions</b>
Driver's Front Airbag
Driver's Pretensioner
ECU locking
Front Passenger(S) Pretensioner(S)
Front thorax side air bag, driver side
Front thorax side air bag, passenger side
Left-Hand Curtain Airbag
Lock Passenger's Airbag With Key
Passenger's Front Airbag
Pretensioner row 1 left-hand side

Pretensioner row 1 right-hand side
Pretensioner row 2 left-hand side
Pretensioner row 2 right-hand side
Reading Impact Contexts
Rear left-hand head-level side airbag
Rear right-hand head-level side airbag
Right-Hand Curtain Airbag
Unlock Computer
Write Date Of Last After Sales Operation
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
<b>AIRBAG AB 8.0 BOSCH -0900-04</b>	✓	✓	⊘	✓
<b>Special Functions</b>				
Air Bag Fault Warning Light				
Computer Locked				
Computer Must Be Replaced				
Driver's Front Airbag				
Driver's Front Airbag Circuit 1				
ECU Status				
Impact information connection				
Lock Passenger's Airbag With Key				
Passenger Front Air Bag Circuit 1				
Passenger's Airbag(S) Locked				
Passenger's Front Airbag				
Unlock Computer				
Vehicle Type				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
<b>AIRBAG AB 8.0 L35 BOSCH -0900-04</b>	✓	✓	⊘	✓
<b>Special Functions</b>				
Driver's Front Airbag				
Driver's Front Buckle Pretensioner				
Driver's Side Sensor				
Driver's Side Thorax Lateral Airbag				
ECU Status				
Ignition Lines Configuration				
Impact information connection				
Lock Passenger's Airbag With Key				
Passenger's Front Airbag				
Passenger's Front Buckle Pretensioner				
Passenger's Side Thorax Lateral Airbag				
Side Passenger Sensor				
Unlock Computer				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
<b>AIRBAG AB9 X77 (MODUS)</b>	✓	✓	⊘	✓
<b>Special Functions</b>				
After-Sales Operation Date				
Airbags Locking				
Airbags Unlocking				
Curtain Side Airbag, Driver's Side				
Curtain Side Airbag, Passenger Side				
Driver Lap Strap Pretensioner				
Driver's Lateral Sensor				
Driver's Seat buckle Sensor				
Driver's Front Airbag Circuit 1				
Driver's Front Airbag Circuit 2				
Driver's Seat Position Sensor				
Front Seat Belt Retractors				
Front Thorax Side Air Bag , Passenger Side				
Front Thorax Side Air Bag, Driver's Side				
Passenger Airbag Locking Mode				
Passenger Lap Strap Pretensioner				
Passenger Presence Detection Sensor				
Passenger's Lateral Sensor				
Passenger's Seat Buckle Sensor				
Passenger's Frontal Airbag Circuit 1				
Passenger's Frontal Airbag Circuit 2				
Rear Inertia Reels				
Vehicle Type				
Write of VIN				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG AB9 X85 (CLIO III)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Air Bag Fault Warning Light</i>				
<i>Computer Locked</i>				
<i>Computer Must Be Replaced</i>				
<i>Curtain Side Airbag, Driver's Side</i>				
<i>Curtain Side Airbag, Passenger Side</i>				
<i>Driver's Front Airbag Circuit 1</i>				
<i>Driver's Front Airbag Circuit 2</i>				
<i>Driver's Lap Strap/Seat Airbag</i>				
<i>Driver's Seat Buckle Sensor</i>				
<i>Driver's Seat Position Sensor</i>				
<i>Driver's Side Sensor</i>				
<i>ECU locking</i>				
<i>Fault/S Memorised</i>				
<i>Front Seat Belt Retractors</i>				
<i>Front thorax side air bag, driver side</i>				
<i>Front thorax side air bag, passenger side</i>				
<i>Locking Supply Diag Outside Limits</i>				
<i>Passenger Air Bag Status Light</i>				
<i>Passenger's Airbag Disable Mode</i>				
<i>Passenger's Airbag(S) Locked</i>				
<i>Passenger's Frontal Airbag Circuit 1</i>				
<i>Passenger's Frontal Airbag Circuit 2</i>				
<i>Passenger's Lap Strap/Seat Airbag</i>				
<i>Rear Inertia Reels</i>				
<i>Side Passenger Sensor</i>				
<i>Unlock Computer</i>				
<i>W Fr Chest Airbags W/Out Head-Lvl Airbags</i>				
<i>With Fr Chest Airbags+Head-Level Airbags</i>				
<i>Without Side Airbags</i>				
<i>Write Date Of Last After Sales Operation</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU3 Avantime	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Curtain Side Airbag, Driver's Side</i>				
<i>Curtain Side Airbag, Passenger Side</i>				
<i>Driver Inertia Reel</i>				
<i>Driver's Lateral Sensor</i>				
<i>Driver's Front Airbag</i>				
<i>Driver's Pretensioner</i>				
<i>Front Thorax Side Airbag Driver side</i>				
<i>Front Thorax side Airbag Passenger Side</i>				
<i>Ignition Module Configuration</i>				
<i>Locking - Unlocking</i>				
<i>Passenger Inertia Reel</i>				
<i>Passenger's Lateral Sensor</i>				
<i>Passenger's Frontal Airbag Circuit 1</i>				
<i>Passenger's Frontal Airbag Circuit 2</i>				
<i>Passenger's Pretensioner</i>				
<i>Side Sensors Configuration</i>				
<i>Vehicle Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU3 MK2 X70	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>After-Sales Operation Date</i>				
<i>Airbags Locking</i>				
<i>Airbags Unlocking</i>				
<i>Vehicle Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU3 MK2 X76	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Configuration of System Components</i>				
<i>Driver's Lateral Sensor</i>				

Driver's Front Airbag
Driver's Front Buckle Pretensioner
Driver's Pretensioner
Front Passenger(s) Pretensioner(s)
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver's Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Impact Information Connection
Locking - Unlocking
Passenger Airbag Locking by Key
Passenger's Lateral Sensor
Passenger's Front Airbag
Passenger's Front Buckle Pretensioner
Side Sensors Configuration
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU3 Renault X83 vdiag20	✓	✓	⊘	✓

Special Functions
Driver Side Front Curtain Airbag
Driver Side Rear Curtain Airbag
Driver's Front Airbag
Driver's Pretensioner
Front Passenger(s) Pretensioner(s)
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver's Side
Front Thorax Side Airbag Driver side
Igniters In Series Configuration
Lock Computer
Passenger Side Front Curtain Airbag
Passenger Side Rear Curtain Airbag
Passenger's Front Airbag
PostSale Repair Date Modification
Pretensioner Row 1 Driver's Side
Pretensioner Row 1 Passenger's Side
Pretensioner Row 2 Driver's Side
Pretensioner Row 2 Passenger's Side
Side On Which Steering Wheel Fitted
Unlock Computer
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG ACU4 (MEGANE II)	✓	✓	⊘	✓

Special Functions
After-Sales Operation Date
Airbags Locking
Airbags Unlocking
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver's Lap Strap/Seat Airbag
Driver's Lateral Sensor
Driver's Seat buckle Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Seat Position Sensor
Front Buckle Pretensioners
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Passenger Airbag Locking Mode
Passenger's Lap Strap/Seat Airbag
Passenger's Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Rear Inertia Reels
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
<b>AIRBAG ACU4 MK2 (MEGANE II)</b>	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>After-Sales Operation Date</i>				
<i>Airbags Locking</i>				
<i>Airbags Unlocking</i>				
<i>Curtain Side Airbag, Driver's Side</i>				
<i>Curtain Side Airbag, Passenger Side</i>				
<i>Driver Side Rear Frontal Airbag</i>				
<i>Driver's Lap Strap/Seat Airbag</i>				
<i>Driver's Lateral Sensor</i>				
<i>Driver's Seat buckle Sensor</i>				
<i>Driver's Seat Sensor</i>				
<i>Driver's Side Rear Strap Sensor</i>				
<i>Driver's Front Airbag Circuit 1</i>				
<i>Driver's Front Airbag Circuit 2</i>				
<i>Front Buckle Pretensimeters</i>				
<i>Front Thorax Side Airbag Driver side</i>				
<i>Front Thorax side Airbag Passenger Side</i>				
<i>Passenger Presence Detection Sensor</i>				
<i>Passenger Side Rear Frontal Airbag</i>				
<i>Passenger Side Rear Strap Sensor</i>				
<i>Passenger's Lap Strap/Seat Airbag</i>				
<i>Passenger's Lateral Sensor</i>				
<i>Passenger's Seat Buckle Sensor</i>				
<i>Passenger's Airbag Disable Mode</i>				
<i>Passenger's Frontal Airbag Circuit 1</i>				
<i>Passenger's Frontal Airbag Circuit 2</i>				
<i>Rear Inertia Reels</i>				
<i>Rear Thorax side Airbag Driver Side</i>				
<i>Rear Thorax Side Airbag Passenger Side</i>				
<i>Side n Which Steering Wheel Fitted</i>				
<i>Vehicle Type</i>				
<i>Write of VIN</i>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>AIRBAG ACU4 MK3-0001-10</b>	✓	✓	✓	✓
<i>Special Functions</i>				
<i>B/C With Fr/Rr Thorax + Head Airbags</i>				
<i>B/C With Front Thorax + Head Airbags</i>				
<i>B/C Without Side Airbags</i>				
<i>Curtain Side Airbag, Driver's Side</i>				
<i>Curtain Side Airbag, Passenger Side</i>				
<i>Driver Side Rear Frontal Airbag</i>				
<i>Driver's Front Airbag Circuit 1</i>				
<i>Driver's Front Airbag Circuit 2</i>				
<i>Driver's Lap Strap/Seat Airbag</i>				
<i>Driver's Seat Buckle Sensor</i>				
<i>Driver's Seat Position Sensor</i>				
<i>Driver's Side Rear Strap Sensor</i>				
<i>Driver's Side Thorax Lateral Airbag</i>				
<i>E With Side Airbags</i>				
<i>E Without Side Airbags</i>				
<i>ECU locking</i>				
<i>Front Buckle Pretensimeters</i>				
<i>G/S With Head Airbags</i>				
<i>G/S Without Head Airbag</i>				
<i>J Without Side Airbags</i>				
<i>J With Side Ab W/O Rear Chest Ab</i>				
<i>K/L With F Chest + Curt Airbags</i>				
<i>K/L With F/R Chest + Curt Airbags</i>				
<i>K/L Without Side Airbags</i>				
<i>Passenger Air Bag Locking Mode</i>				
<i>Passenger Front Air Bag Circuit 1</i>				
<i>Passenger Presence Detection Sensor</i>				
<i>Passenger Side Rear Frontal Airbag</i>				
<i>Passenger Side Rear Strap Sensor</i>				
<i>Passenger's Frontal Airbag Circuit 2</i>				
<i>Passenger's Lap Strap/Seat Airbag</i>				
<i>Passenger's Seat Buckle Sensor</i>				
<i>Passenger's Side Thorax Lateral Airbag</i>				

Rear Driver's Side Thorax Lateral Airbag				
Rear Inertia Reels				
Rear Passenger Side Thorax Lateral Airbag				
Side On Which Steering Wheel Fitted				
Unlock Computer				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
AIRBAG AUTOLIV AC4 ph1 version X	✓	✓	⊘	✓
<b>Special Functions</b>				
Airbags Locking				
Airbags Unlocking				
Driver's Front Airbag				
Driver's Pretensioner				
Passenger's Front Airbag				
Passenger's Pretensioner				
PostSale Repair Date Modification				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
AIRBAG AUTOLIV AC4 ph2	✓	✓	⊘	✓
<b>Special Functions</b>				
Airbags Locking				
Airbags Unlocking				
Crash Information Output				
Driver's Front Airbag				
Driver's Pretensioner				
Passenger's Front Airbag				
Passenger's Frontal Airbag Locking				
Passenger's Frontal Airbag Unlocking				
Passenger's Pretensioner				
PostSale Repair Date Modification				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
AIRBAG AUTOLIV AC6 ph1 version 01	✓	✓	⊘	✓
<b>Special Functions</b>				
Airbags Locking				
Airbags Unlocking				
Driver's Side Airbag				
Driver's Front Airbag				
Driver's Pretensioner				
Driver's Side Sensor				
Passenger's Side Airbag				
Passenger's Front Airbag				
Passenger's Pretensioner				
PostSale Repair Date Modification				
Side Passenger Sensor				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
AIRBAG AUTOLIV AC6 ph2	✓	✓	⊘	✓
<b>Special Functions</b>				
Airbags Locking				
Airbags Unlocking				
Crash Information Output				
Driver's Side Airbag				
Driver's Front Airbag				
Driver's Pretensioner				
Driver's Side Sensor				
Passenger's Side Airbag				
Passenger's Front Airbag				
Passenger's Frontal Airbag Locking				
Passenger's Frontal Airbag Unlocking				
Passenger's Pretensioner				
PostSale Repair Date Modification				
Side Passenger Sensor				
Side Sensors Configuration Setup				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
AIRBAG AUTOLIV ACU3 x64 - x06	✓	✓	⊘	✓
<b>Special Functions</b>				
Configuration of System Components				
Curtain Side Air Bag, Driver's Side				
Curtain Side Air Bag, Passenger Side				

Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver's Lateral Sensor
Driver's Front Airbag
Front Pretensioners
Front Pretensioners Circuit
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver's Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Impact Information Connection
ISOFIX Function
Lock / Unlock Passenger's Front Air Bag
Locking - Unlocking
Passenger Air Bag Locking Type
Passenger Airbag Locking by Key
Passenger's Lateral Sensor
Passenger's Front Airbag
PostSale Repair Date Modification
Rear Inertia Reels / Pretensioners
Rear Inertial Reel/Pretensioner Circuits
Side Sensors Configuration
Vehicle Type

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG AUTOLIV ACU3 X83	✓	✓	⊘	✓

Special Functions
Driver's Lateral Sensor
Driver's Front Airbag
Driver's Pretensioner
Front Passenger(s) Pretensioner(s)
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver's Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Igniters In Series Configuration
Ignition Module Configuration
Locking - Unlocking
Passenger's Lateral Sensor
Passenger's Front Airbag
PostSale Repair Date Modification
Pretensioner Row 1 Driver's Side
Pretensioner Row 1 Passenger's Side
Pretensioner Row 2 Driver's Side
Pretensioner Row 2 Passenger's Side
Side Sensors Configuration
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG AUTOLIV EC5	✓	✓	⊘	✓

Special Functions
Airbags Locking
Airbags Unlocking
Driver's Front Airbag
Driver's Pretensioner
Passenger's Front Airbag
Passenger's Pretensioner
PostSale Repair Date Modification

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BACU81-315-28	✓	✓	⊘	✓

Special Functions
Driver Lap Strap Pretensioner
Driver Side Front Curtain Air Bag
Driver Side Rear Curtain Air Bag
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Driver's Seat Sensor
Driver's Side Thorax Lateral Airbag
ECU locking

Front Buckle Pretensioners
Lock Passenger's Airbag With Key
Passenger Lap Strap Pretensioner
Passenger Side Front Curtain Air Bag
Passenger Side Rear Curtain Air Bag
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Passenger's Side Thorax Lateral Airbag
Reading Impact Contexts
Rear Driver's Side Thorax Lateral Airbag
Rear Passenger Side Thorax Lateral Airbag
Side On Which Steering Wheel Fitted
Unlock Computer
Vehicle Type
Write Date Of Last After Sales Operation
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BOSCH AB 7.0	✓	✓	⊘	✓
Special Functions				
Airbags Locking				
Airbags Unlocking				
Passenger's Front Airbag				
PostSale Repair Date Modification				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BOSCH AB 8.0	✓	✓	⊘	✓
Special Functions				
Airbag disabling switch				
Airbags Locking				
Airbags Unlocking				
Crash Information Output				
Driver's Front Airbag				
Driver's Pretensioner				
Driver's Seat Position Sensor				
Passenger's Front Airbag				
Passenger's Frontal Airbag Locking				
Passenger's Frontal Airbag Unlocking				
Passenger's Pretensioner				
Passenger's Seat Position Sensor				
PostSale Repair Date Modification				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BOSCH AB 8.1	✓	✓	⊘	✓
Special Functions				
Airbag disabling switch				
Airbags Locking				
Airbags Unlocking				
Crash Information Output				
Driver's Side Airbag				
Driver's Front Airbag				
Driver's Pretensioner				
Driver's Seat Position Sensor				
Driver's Side Sensor				
Passenger's Side Airbag				
Passenger's Front Airbag				
Passenger's Frontal Airbag Locking				
Passenger's Frontal Airbag Unlocking				
Passenger's Pretensioner				
Passenger's Seat Position Sensor				
PostSale Repair Date Modification				
Side Passenger Sensor				
Side Sensors Configuration Setup				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BOSCH AB 8.2 X65 Ph2	✓	✓	⊘	✓
Special Functions				
Airbags Locking				
Airbags Unlocking				
Driver Pretensioner Circuit Resistance				
Driver's Front Airbag Circuit 1				
Driver's Front Airbag Circuit 2				

Driver's Seat Position Sensor
Driver's Side Head Lateral Airbag
Driver's Side Rear Reel
Driver's Side Sensor
Driver's Side Thorax Lateral Airbag
Passenger Pretensioner Circuit Resistance
Passenger's Airbag Disable Mode
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Passenger's Side Head Lateral Airbag
Passenger's Side Rear Reel
Passenger's Side Thorax Lateral Airbag
PostSale Repair Date Modification
Side Passenger Sensor

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BOSCH AB8.1_02_08	✓	✓	⊘	✓

<b>Special Functions</b>
Configuration of System Components
Driver's Side Airbag
Driver's Front Airbag
Driver's Pretensioner
Driver's Side Sensor
ECU Status
Impact Connection
Lock Passenger's Airbag With Key
Passenger's Side Airbag
Passenger's Front Airbag
Passenger's Frontal Airbag Locking
Passenger's Frontal Airbag Unlocking
Passenger's Pretensioner
Side Passenger Sensor
Side Sensors Configuration Setup
Unlock Computer
Write Date Of Last After Sales Operation

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BX7374 VD24-315-24	✓	✓	⊘	✓

<b>Special Functions</b>
Configuration of System Components
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners
Driver's Seat Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Seat Inertia Reel Locking
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Lock Computer
Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side On Which Steering Wheel Fitted
Unlock Computer
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG BX7374 VD2C-315-2C	✓	✓	⊘	✓

<b>Special Functions</b>
Configuration of System Components
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner

Driver Side Loop Pretensioners
Driver's Seat Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Seat Inertia Reel Locking
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Lock Computer
Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side On Which Steering Wheel Fitted
Unlock Computer
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG MATRA SDM (SPACE)	✓	✓	⊘	✓
<b>Special Functions</b>				
Fuel Pump Cut Off Configuration				
Locking - Unlocking				
PostSale Repair Date Modification				
Side Airbags				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG TEMIC L35-0000-10	✓	✓	⊘	✓
<b>Special Functions</b>				
Driver's Front Airbag				
Driver's Front Buckle Pretensioner				
Driver's Front Side Impact Sensor				
Driver's Seat Buckle Sensor				
Driver's Side Thorax Lateral Airbag				
ECU locking				
Impact information connection				
Pass Airbag Deactivation Warning Light				
Passenger Airbag Locking Mode				
Passenger's Front Airbag				
Passenger's Front Buckle Pretensioner				
Passenger's Front Side Impact Sensor				
Passenger's Side Thorax Lateral Airbag				
Reading Impact Contexts				
Seat Belt Light				
Seat Belt Reminder Buzzer				
Side On Which Steering Wheel Fitted				
Unlock Computer				
Vehicle Type				
Without inhibition switch				
Write Vin				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG TEMIC X90_VDIAG_04_B2-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Air Bag Fault Warning Light				
Computer Must Be Replaced				
Driver's Front Airbag				
Driver's Front Airbag Circuit 1				
Driver's Front Buckle Pretensioner				
Driver's Front Side Impact Sensor				
Driver's Seat Buckle Sensor				
Driver's Side Thorax Lateral Airbag				
ECU Disabled				
ECU Status				
Fault/S Memorised				
Front Driver Inertia Reel				
Front Passenger Inertia Reel				
Impact information connection				

Locking Supply Diag Outside Limits
Pass Airbag Deactivation Warning Light
Passenger Air Bag Locking Mode
Passenger Air Bag Status Light
Passenger's Air Bag Locked
Passenger's Airbag Disable Mode
Passenger's Front Airbag
Passenger's Front Buckle Pretensioner
Passenger's Front Side Impact Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Side Thorax Lateral Airbag
Seat Belt Light
Seat Belt Reminder Buzzer
Side On Which Steering Wheel Fitted
Unlock Computer
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG_MRSZ_X44_VDIAG04-0000-04	✓	✓	⊘	✓

Special Functions
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver's Front Airbag
Driver's Front Buckle Pretensioner
Driver's Front Side Impact Sensor
Driver's Seat Buckle Sensor
Front thorax side air bag, driver side
Front thorax side air bag, passenger side
Lock Computer
Passenger Air Bag Locking Mode
Passenger's Front Airbag
Passenger's Front Buckle Pretensioner
Passenger's Front Side Impact Sensor
Side On Which Steering Wheel Fitted
Unlock Computer
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG-315-0C	✓	✓	✓	✓

Special Functions
Configuration of System Components
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners
Driver's Lateral Sensor
Driver's Seat Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Lock Computer
Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger's Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side Sensors Configuration
Unlock Computer
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AIRBAG-315-14	✓	✓	⊘	✓

Special Functions
Configuration of System Components
Curtain Side Air Bag, Driver's Side
Curtain Side Air Bag, Passenger Side

Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Loop Pretensioners
Driver's Lateral Sensor
Driver's Seat Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Seat Inertia Reel Locking
Front Thorax Side Air Bag , Passenger Side
Front Thorax Side Air Bag, Driver's Side
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Locking - Unlocking
Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Loop Pretensioners
Passenger's Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax Side Air Bag , Driver Side
Rear Thorax Side Air Bag , Passenger Side
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side Sensors Configuration
Vehicle Type
VIN Code

ECU	Trouble Codes	Live Data	Actuators	Special Functions
<b>AIRBAG-315-18</b>	✓	✓	⊘	✓

<b>Special Functions</b>
Configuration of System Components
Curtain Side Airbag, Driver's Side
Curtain Side Airbag, Passenger Side
Driver Lap Strap Pretensioner
Driver Side Rear Curtain Airbag
Driver's Lateral Sensor
Driver's Seat Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Buckle Pretensioners
Front Thorax Side Airbag Driver side
Front Thorax side Airbag Passenger Side
Ignition Module Configuration
Lock Computer
Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Rear Curtain Airbag
Passenger's Lateral Sensor
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
Rear Thorax side Airbag Driver Side
Rear Thorax Side Airbag Passenger Side
Side Sensor Configuration
Unlock Computer
Write Date Of Last After Sales Operation
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
<b>AIRBAG-315-2D</b>	✓	✓	⊘	✓

<b>Special Functions</b>
Driver Lap Strap Pretensioner
Driver Side Front Curtain Airbag
Driver Side Rear Curtain Airbag
Driver's Seat Sensor
Driver's Front Airbag Circuit 1
Driver's Front Airbag Circuit 2
Front Buckle Pretensioners
Front Thorax Side Air Bag, Driver's Side
Front Thorax side Airbag Passenger Side

Lock Computer
Passenger Airbag Locking by Key
Passenger Lap Strap Pretensioner
Passenger Side Front Curtain Airbag
Passenger Side Rear Curtain Airbag
Passenger's Frontal Airbag Circuit 1
Passenger's Frontal Airbag Circuit 2
PostSale Repair Date Modification
Rear Thorax Side Air Bag , Driver Side
Rear Thorax Side Airbag Passenger Side
Side On Which Steering Wheel Fitted
Unlock Computer
Vehicle Type
Write of VIN

#### AUTOMATIC GEARBOX

ECU	Trouble Codes	Live Data	Actuators	Special Functions
AUTOMATIC GEARBOX BVR-X65		✓	✓	✓
<i>Special Functions</i>				
Clutch Initial Closed Position				
Programme Slip Point				
Programmed Values				
Programming Selection / Engaging Zones				
Write Clutch Initial Closed Position				
Write Date New Clutch Fitted				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AUTOMATIC GEARBOX BVA SU1-0450-04	✓	✓	✓	✓
<i>Special Functions</i>				
Auto-Adaptives				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AUTOMATIC GEARBOX BVR_JA_AV_PALETTE_J77_X85-00FC-18	✓	✓	✓	✓
<i>Special Functions</i>				
Program Clutch Open Position				
Programming Selection / Engaging Zones				
Write Clutch Initial Closed Position				
Write Date New Clutch Fitted				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AUTOMATIC GEARBOX BVR-X70 X83		✓	✓	✓
<i>Special Functions</i>				
Clutch Initial Closed Position				
Program Clutch Open Position				
Programme Slip Point				
Programmed Values				
Programming Selection / Engaging Zones				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
AUTOMATIC GEARBOX DP0-TA2000-APV	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning With Wire Connection				
Check Motor Torque by ABS				
Converter Lock Up Adaptative				
OBD Memory				
Selector Lever Locking				
Trajectory Control				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
BVA A 4.2 AUTOMATIC GEARBOX	✓	✓	✓	
BVA AJO X91-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
Erase Auto-Adaptive Values				
Manual Mode				
Sensor Configuration				

Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA DP0 Ta2000-0000-04	✓	✓	✓	✓
Special Functions				
Auto-Adaptives				
Note Oil Wear Counter				
VIN code				
Write Date Of Last After Sales Operation				
Write Transmission Oil Change Date				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA DP0 Ta2000-00NA-10	✓	✓	✓	✓
Special Functions				
Auto-Adaptives				
Converter Lock Up Adaptive				
Write Date Of Last After Sales Operation				
Write of VIN				
Write Transmission Oil Change Date				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA DP0 X61-9400-04	✓	✓	✓	✓
Special Functions				
Auto-Adaptives				
Diff. Between Setting And Oil Pressure				
Note Oil Wear Counter				
Write Date Of Last After Sales Operation				
Write of VIN				
Write Transmission Oil Change Date				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA DP0 X84 Ph2-0000-141818	✓	✓	✓	✓
Special Functions				
Auto-Adaptives				
Note Oil Wear Counter				
Write Date Of Last After Sales Operation				
Write Transmission Oil Change Date				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA_CVT_H45-0000-04	✓	✓	⊘	✓
Special Functions				
Reset Oil Change Counter				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA_DC4_X95_VD04-0410-04	✓	✓	✓	✓
Special Functions				
Erase Auto-Adaptive Values				
Program clutch adjustment				
Program clutch assembly				
Programme Clutch Position				
Programming Selection/Engaging Zones				
Shift drum reference position				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVA_DP0_TA2005-NS20-04	✓	✓	✓	✓
Special Functions				
Auto-Adaptives				
Note Oil Wear Counter				
Write Date Of Last After Sales Operation				
Write Transmission Oil Change Date				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVR_JH_AV_PALETTE_X44-5246-04	✓	✓	✓	✓
Special Functions				
Clutch Initial Closed Position				
Configurations				
Programme Slip Point				
Programming Selection/Engaging Zones				
Write Clutch Initial Closed Position				
Write Date New Clutch Fitted				

Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BVR-X70ph3 X83ph2-0000-05		✓	✓	✓
<b>Special Functions</b>				
Clearing of fault code(s)				
Clutch Initial Closed Position				
Configurations				
Fault reading				
Program Clutch Open Position				
Programme Slip Point				
Programming Selection/Engaging Zones				
Write Clutch Initial Closed Position				
Write Date New Clutch Fitted				
Write Date Of Last After Sales Operation				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CAMBIOS AUTOMATICOS BVA DPO Ta2000-0000-00	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning Output Use				
Air Conditioning With Wire Connection				
Auto-Adaptives				
Check Motor Torque By Abs				
Controlled Slip				
Converter Lock Up Adaptive				
Declutch When Stationary				
Dialogue In Couple				
Ignition On				
Linked To Turbine Speed				
OBD Memory				
Selector Lever Locking				
Trajectory Control				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPO AUTOMATIC GEARBOX	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning				
Distance Before Next Oil Change				
OBD				
Pedal Learning				
PostSale Repair Date Modification				
Reset Auto-Adaptive Values				
Reset the Oil Aging Counter				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPO_L90_VD04_NS10-NS10-04	✓	✓	✓	✓
<b>Special Functions</b>				
Auto-Adaptives				
Note Oil Wear Counter				
Write Date Of Last After Sales Operation				
Write Transmission Oil Change Date				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPO-TA2000-APV soft82	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning Connection Fault Finding				
Auto-Adaptives				
Engine Torque Control Function				
Lever Locking Connection Fault Finding				
Note Oil Wear Counter				
Programming Of No Load And Full Load Positions				
Trajectory Control Function				
Write Date Of Last After Sales Operation				
Write of VIN				
Write Transmission Oil Change Date				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPO-TA2005-L35-N560-08	✓	✓	✓	✓
<b>Special Functions</b>				

Auto-Adaptives				
Note Oil Wear Counter				
Write Date Of Last After Sales Operation				
Write Transmission Oil Change Date				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DP2_Px_VD08-Px-08	✓	✓	✓	✓
<i>Special Functions</i>				
Auto-Adaptives				
Note Oil Wear Counter				
Write Date Of Last After Sales Operation				
Write Transmission Oil Change Date				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ISO M4.2 AUTOMATIC GEARBOX	✓	✓	✓	👤
ISO M4.3 AUTOMATIC GEARBOX	✓	✓	✓	👤
SU1 AUTOMATIC GEARBOX 2001	✓	✓	✓	✓
<i>Special Functions</i>				
Reset self-adaptation parameters				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SU1 AUTOMATIC GEARBOX apv	✓	✓	✓	✓
<i>Special Functions</i>				
Reset self-adaptation parameters				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ZF LM0 AUTOMATIC GEARBOX	✓	✓	👤	✓
<i>Special Functions</i>				
Reset Auto-Adaptive Values				
<b>CLIMATRONIC CONTROL</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
AIR CONDITIONING BAC-ECO	✓	✓	✓	✓
<i>Special Functions</i>				
Coolant Sensor				
Evaporator Temperature Sensor				
Recycling Flap Auto-Setting				
Recycling Motor Timer				
Test Configuration				
Type Compressor				
Type Control				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CAREG X44 _VDIAG 44_V01-0000-44	✓	✓	✓	✓
<i>Special Functions</i>				
Geographical Zone				
Heating Resistor Type				
Vehicle Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM BAC	✓	✓	✓	✓
<i>Special Functions</i>				
Behr Probe Configuration				
Compressor Type				
Control Type				
Eeprom Probe Configuration				
Evaporator Temperature Sensor				
Hokuriku Probe Configuration				
Recycling Flap Auto-Setting				
Recycling Motor Timer				
Refrigerant Sensor				
Siemens Probe Configuration				
Window Heater				
Write Date Of Last After Sales Operation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM REGULEE X61-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				

Bodywork Type				
Driving Type				
Geographical Zone				
Heating Resistor Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM X91-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Compressor Type				
Computer Initialisation				
Geographical Zone				
Vehicle Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM. J77 VDIAG44-0500-44	✓	✓	✓	✓
<b>Special Functions</b>				
Geographical Zone				
Heating Resistor Type				
Vehicle Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM. REGULEE - 002 - 09	✓	✓	✓	✓
<b>Special Functions</b>				
Compressor Type				
Drive Ratio				
Evaporator Temperature Sensor				
Heated Windscreen				
Type Of Power Steering				
Vehicle Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM. X85 VDIAG 44-0501-44	✓	✓	✓	✓
<b>Special Functions</b>				
Geographical Zone				
Heating Resistor Type				
Vehicle Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIM_REGULEE J81 VDIAG 0D-0001-0D	✓	✓	✓	✓
<b>Special Functions</b>				
Additional Heating				
Air Conditioning Type				
Alternator type				
Compressor Type				
Drive Ratio				
Driving Type				
Geographical Zone				
Heating Resistor Type				
Presence Of Rear Panels				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIMATIZACIÓN X65 Régulée	✓	✓	✓	⊘
CLIMATIZATION MANUAL-000-08	✓	✓	✓	✓
<b>Special Functions</b>				
Compressor Type				
Drive Ratio				
Engine Cooling Fan Signal By Injection				
Engine Type				
Evaporator Temperature Sensor				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
CLIMATIZATION REGULEE (MEGANE II)	✓	✓	⊘	✓
<b>Special Functions</b>				
Heating Resistor Type				
Vehicle Type				
Write of VIN				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
CLIMATIZATION REGULEE J81 VDIAG 11-0000-11	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Additional Heating</i>				
<i>Air Conditioning Type</i>				
<i>Alternator type</i>				
<i>Compressor Type</i>				
<i>Drive Ratio</i>				
<i>Driving Type</i>				
<i>Geographical Zone</i>				
<i>Heating Resistor Type</i>				
<i>Rear Shelves</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
CLIMATRONIC X74 X73	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Compressor Type</i>				
<i>Drive Ratio</i>				
<i>Evaporator Temperature Sensor</i>				
<i>Heater Windscreen Information</i>				
<i>Steering Type Configuration</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
L35_CAREG-00-06	✓	✓	✓	⚠
REGULATED CLIMATRONIC J64	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Side On Which Steering Wheel Fitted</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
REGULATED CLIMATRONIC J66 - D66	✓	✓	⚠	✓
<i>Special Functions</i>				
<i>Avantime (F4r): With Heated Windscreen</i>				
<i>Avantime (F4r): Without Heated Windscreen</i>				
<i>Avantime(Except F4r):With Heated Windscr.</i>				
<i>Avantime(Expt F4r):Without Heated Windscr.</i>				
<i>Evaporator Sensor</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
REGULATED CLIMATRONIC X56	✓	✓	✓	👤
REGULATED CLIMATRONIC X74	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Additional heating</i>				
<i>Compressor Type</i>				
<i>Drive Ratio</i>				
<i>Evaporator Temperature Sensor</i>				
<i>Heater Windscreen Information</i>				
<i>Steering Type Configuration</i>				
<i>Vehicle Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
X95_CAREG-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Computer Reinitialisation</i>				
<i>Write Vin</i>				
DISCHARGE LAMP				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
COMPUTER DISCHARGE LAMP- 000- 01	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Vehicle Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
COSLAD P52 J66 (Espace)	✓	✓	✓	⚠
COSLAD X65	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Engine Type</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DISCHARGE LAMP (CAN)	✓	✓	✓	✓

<b>Special Functions</b>				
Left - Hand Correction				
Right - Hand Correction				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DISCHARGE LAMP-000-45	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic Fold - Down Headlights				
Cornering Lights				
Dipped Headlights Raise				
Dynamic Correction				
Signature				
System Initialisation				
Vehicle Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
FEUX DE VIRAGE-000-46	✓	✓	✓	✓
<b>Special Functions</b>				
Cornering Lights				
Headlight Heat Timer				
Indicator Management For Cornering Lights				
Vehicle Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
LAD J84-0101-05	✓	✓	✓	✓
<b>Special Functions</b>				
Vehicle Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
LAM X91 -0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
System Initialisation				
Vin Code				
<b>DRIVER'S DOOR MODULE</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
LDCM X91-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Frost management mode				
Write Vin				
<b>ELECTRICAL SUPERVISOR</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SUPER x76 soft B2. YY RNUR	✓	✓	✓	✓
<b>Special Functions</b>				
100 Ah Traction Battery				
Maintenance Charge Request				
Range Extender				
Reinitialise Direction Of Movement				
Reinitialise Full Load Accel Pot'tiometer				
Reinitialise No Load Accelerator Potentiometer				
<b>ELECTRONIC CLUTCH</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ELECTRONIC CLUTCH X06	✓	✓	✓	✓
<b>Special Functions</b>				
Clutch Cylinder and Solenoid Valves Zero Position Memorization				
PostSale Repair Date Modification				
<b>ELECTRONIC DASHBOARD</b>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
COMPUTER INSTRUMENT PANEL- 0001-04	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic Handbrake				
Consumption Measurement Units				
Cruise Control / Speed Limiter				
Distance Units				
Fuel Type				
Hands Free				

Language Version				
Lights Automatic Illumination				
Navigation				
Other AT				
Other Manual				
Overspeed Function - Arabia				
Temperature Units				
Trajectory Control				
Tyre Pressure Monitoring				
Tyre Pressure Units				
V4y Auto Box				
V4y Manual				
Vehicle Type				
Voice Synthesizer				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
COMPUTER INSTRUMENT PANEL 00001-04	✓	✓	⊘	✓
<b>Special Functions</b>				
Distance Regulator				
GearBox Type				
Language Version				
Tyre Pressure Units				
Vehicle Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
COMPUTER INSTRUMENT PANEL -0008-0C	✓	✓	⊘	✓
<b>Special Functions</b>				
Distance Regulator				
Language Version				
Other AT				
Other Manual				
P9x At				
P9x Manual				
Tyre Pressure Units				
V4y Auto Box				
V4y Manual				
Vehicle Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ELECTRONIC DASHBOARD X56	✓	✓	⊘	✓
<b>Special Functions</b>				
5 cylinder ECU Programming				
ECU Programming with 4 Cylinders				
ECU Programming with 6 Cylinders				
ECU Programming with Immobilizer Type 1				
ECU Programming with Immobilizer Type 2				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INSTRUMENT PANEL (MODUS)	✓	✓	✓	👤
INSTRUMENT PANEL 0410-08	✓	✓	✓	✓
<b>Special Functions</b>				
Bodywork type				
Card/Key				
Clock				
Consumption Measurement Units				
Cruise ctrl/Spd limiter				
Distance Units				
Fuel Gauge Calibration				
Fuel type				
Gearbox Type				
Language Configuration				
Lights Automatic Illumination				
O.C.S.				
Oil Change Interval In Km				
Oil Change Interval In Months				
Oil Change Range:Current Value In Km				
Oil Change Range:Current Value In Months				
Overspeed Function - Arabia				
Particle filter				
Reserve Capacity				

Rheostat presence
Seat Belt Reminder Buzzer
Tank capacity
Tyre Pressure Monitoring
Update Odometer
Vehicle Speed Signal Transmitter
Vehicle Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INSTRUMENT PANEL X74 vdiag 16	✓	✓	⊘	✓

<b>Special Functions</b>
Distance Before Next Oil Change
Distance Regulator
Engine / Gearbox Type
Language Version
Seat Belt not Fastened Buzzer
Tyre Pressure
Vehicle Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INSTRUMENT PANEL X85ph2-55-10	✓	✓	✓	✓

<b>Special Functions</b>
Bodywork type
Card/Key
Clock
Consumption Measurement Units
Cruise ctrl/Spd limiter
Distance Units
Fuel Gauge Calibration
Fuel type
Gearbox Type
Language Configuration
Lights Automatic Illumination
O.C.S.
Oil Change Interval In Km
Oil Change Interval In Months
Oil Change Range:Current Value In Km
Oil Change Range:Current Value In Months
Overspeed Function - Arabia
Particle filter
Reserve Capacity
Rheostat presence
Seat Belt Reminder Buzzer
Tank capacity
Tyre Pressure Monitoring
Update Odometer
Vehicle Speed Signal Transmitter
Vehicle Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INSTRUMENT PANEL-0004A-10	✓	✓	✓	✓

<b>Special Functions</b>
Adac Display Type
Cruise Contr./Sp. limit speed diff.
Cruise ctrl/Spd limiter
Directional Headlights
Distance Units
Fuel type
Gearbox type
Language Version
Lights Automatic Illumination
Odometer In Km
Odometer In Miles
Oil Change Interval In Km
Oil Change Interval In Miles
Oil Change Interval In Months
Oil Change Range: Current Value In Miles
Oil Change Range:Current Value In Km
Oil Change Range:Current Value In Months

Oil measurement				
Oil measurement timer				
Oil pressure warngin threshold				
Oil Service And Odometry Miles - Km				
Oil temperature measuremente threshold				
Overspeed Function - Arabia				
Parking Aid				
Particle Filter				
Trajectory Control				
Tyre Pressure Monitoring				
Tyre Pressure Units				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INSTRUMENT PANEL-001-04	✓	✓	⊘	✓
Special Functions				
Automatic Handbrake				
Consumption Measurement Units				
Cruise Control / Speed Limiter				
Distance Units				
Fuel Type				
GearBox Type				
Language				
Oil Change Interval in Miles				
Oil Change Interval in Months				
Overspeed Function - Arabia				
Trajectory Control				
Tyre Pressure Monitoring				
Vehicle Type				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INSTRUMENT PANEL-001-08 (SCENIC II)	✓	✓	✓	✓
Special Functions				
Automatic Handbrake				
Consumption Measurement Units				
Cruise Control / Speed Limiter				
Distance Units				
Fuel type				
GearBox Type				
Language				
Oil Change Interval in Miles				
Oil Change Interval in Months				
Overspeed Function - Arabia				
Trajectory Control				
Tyre Pressure Monitoring				
Vehicle Type				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INSTRUMENT PANEL-04A-11	✓	✓	✓	✓
Special Functions				
Adac Display Type				
Automatic Handbrake				
Cruise Contr./Sp. limit speed diff.				
Cruise ctrl/Spd limiter				
Distance Units				
Fuel Gauge Calibration				
Fuel type				
Gas Reserv. Capac.				
Gearbox Type				
Language Version				
Lights Automatic Illumination				
Oil Change Interval In Km				
Oil Change Interval In Months				
Oil Change Range:Current Value In Km				
Oil Change Range:Current Value In Months				
Overspeed Function - Arabia				
Particle filter				
Reserve Capacity				
Seat Belt Reminder Buzzer				
Tank capacity				

Trajectory Control			
Tyre Pressure Monitoring			
Tyre Pressure Units			
Uch			
Update Odometer			
Vehicle Type			
Voice Synthesiser			
Write Vin			
<b>ECU</b>			
<b>INSTRUMENT PANEL-4.1-04</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓
<i>Special Functions</i>			
Arabian Overspeed			
Consumption Measurement Units			
Cruise Control / Speed Limiter			
Distance Units			
Fuel Type			
GearBox Type			
Language			
Oil Change Interval in Miles			
Oil Change Interval in Months			
Reserve Capacity			
Trajectory Control			
Tyre Pressure Monitoring			
Vehicle Type			
Write of VIN			
<b>ECU</b>			
<b>INSTRUMENT PANEL-400-08</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓
<i>Special Functions</i>			
Bodywork type			
Card/Key			
Clock			
Consumption Measurement Units			
Cruise Control / Speed Limiter			
Distance Units			
GearBox Type			
Language			
Lights Automatic Illumination			
Odometer Update			
Oil Change Interval in Miles			
Oil Change Interval in Months			
Overspeed Function - Arabia			
Particle Filter			
Reserve Capacity			
Rheostat Prescence			
Seat Belt Reminder Buzzer			
Tank Capacity			
Tyre Pressure Monitoring			
Vehicle Speed Signal Transimter			
Write of VIN			
<b>ECU</b>			
<b>TABLEAU DE BORD X44-0000-04</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓
<i>Special Functions</i>			
Cruise ctrl/Spd limiter			
Display fuel level actualization			
Distance Units			
Electric Power Assisted Steering			
External Temperature			
Fuel Type			
Gearbox Type			
O.C.S.			
Oil Service And Odometry Miles - Km			
Overspeed Function - Arabia			
Rheostat presence			
Seat Belt Reminder Buzzer			
Trajectory Control			
Write Vin			
<b>ECU</b>			
<b>TDB JR95-0000-24</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓

<b>Special Functions</b>				
Adac Display Type				
Computer Initialisation				
Conectivity Portable Computer				
Cruise ctrl/Spd limiter				
Distance before next oil change				
Distance Units				
Gearbox type				
Language Version				
Overspeed Alarm				
Present Navigation				
Radio Type				
Tyre Pressure Monitor Function				
Tyre Pressure Units				
Volume Unit				
Write of VIN				
<b>ECU</b>				
TDB L38-0000-05-0000-05				
Trouble Codes				
Live Data				
Actuators				
Special Functions				
✓				
✓				
✓				
✓				
<b>Special Functions</b>				
Adac Display Type				
Computer Initialisation				
Consumption Measurement Units				
Cruise ctrl/Spd limiter				
Distance before next oil change				
Distance Units				
Gearbox Type				
Language Version				
Overspeed Alarm				
Tyre Pressure Monitor Function				
Tyre Pressure Units				
Write Vin				
<b>ECU</b>				
TDB X91 -0000-10				
Trouble Codes				
Live Data				
Actuators				
Special Functions				
✓				
✓				
✓				
✓				
<b>Special Functions</b>				
Adac Display Type				
Consumption Measurement Units				
Cruise ctrl/Spd limiter				
Distance before next oil change				
Distance Units				
Language Version				
Overspeed Alarm				
Tyre Pressure Monitor Function				
Tyre Pressure Units				
Write Vin				
<b>ECU</b>				
TDB X95-0000-04				
Trouble Codes				
Live Data				
Actuators				
Special Functions				
✓				
✓				
✓				
✓				
<b>Special Functions</b>				
Adac Display Type				
Consumption Measurement Units				
Cruise ctrl/Spd limiter				
Distance before next oil change				
Distance Units				
EEPROM Memory Write Procedure				
Gearbox type				
Language Version				
Overspeed Alarm				
Tyre Pressure Monitor Function				
Tyre Pressure Units				
Write Vin				
<b>ECU</b>				
TDB_METER_H45_2-0000-08				
Trouble Codes				
Live Data				
Actuators				
Special Functions				
✓				
✓				
🛑				
✓				
<b>Special Functions</b>				
Adac Display Type				
Consumption Measurement Units				
Day back-lighting				
Distance before next oil change				
Distance Units				
Free Shift				

Free Shift Display
I.V.P.
Language Configuration
Needle Activation
Overspeed Alarm
Seat Belt Reminder Buzzer
Slope sensor adjustment
Trajectory Control
Type Parking Brake
Tyre Pressure Monitor Function

ECU	Trouble Codes	Live Data	Actuators	Special Functions
TDB_METER_H45-0000-04	✓	✓	🛑	✓
Special Functions				
Language Version				
Slope sensor adjustment				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
TDB_X61-003D-04	✓	✓	✓	✓
Special Functions				
Adac Configuration				
Adac Display Type				
Clock				
Cruise ctrl/Spd limiter				
Distance Units				
Driving Type				
External Temperature				
Fuel gauge calibration, estandar instrument cluster				
Fuel Gauge Calibration, MDG-HDG instrument cluster				
Fuel Type				
Gearbox Type				
Language Configuration				
Lights Automatic Illumination				
O.C.S.				
Oil Change Interval In Km				
Oil Change Interval In Months				
Oil Change Range:Current Value In Km				
Oil Change Range:Current Value In Months				
Overspeed Function - Arabia				
Restart The Computer				
Rev Counter				
Save / Write Data Computer Replacement				
Seat Belt Warning module				
Trajectory Control				
Update Odometer				
Write Date Of Last After Sales Operation				
Write Vin				

**ELECTRONIC SUSPENSION (EAS)**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
PILOTED SUSPENSION X70	✓	✓	✓	✓
Special Functions				
Write Date Of Last After Sales Operation				

**ENGINE ELECTRONICS (LPG)**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
LPG 2000	👤	👤	👤	👤

**ENGINE ELECTRONICS (PETROL/DIESEL)**

ECU	Trouble Codes	Live Data	Actuators	Special Functions
BOSCH AS 3.3	👤	👤	✓	👤
BOSCH EDC 15C - Vdiag OC X83	✓	✓	✓	✓
Special Functions				
Air Conditioning				
CAN Bus				
EGR Type				
Flow Regulation Type				
Gear Box Type				
Idle Speed Decrease				
Idle Speed Increase				
Injection Type				
Inlet Type				

Number of Cylinders				
Thermoplunger				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BOSCH EDC 15C - VDIAG 0C X70	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Decrement Idle Speed				
Increment of idle speed				
Thermoplunger				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BOSCH EDC 15C - Vdiag 10 X64 Calib2	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Idle Speed Decrease				
Idle Speed Increase				
Thermoplunger				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BOSCH EDC 15C - VDIAG 14 - X76 X64	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Boiler				
ECU replacement				
Enter Injector Codes				
Flow Regulation Type				
GearBox Type				
IMA Programming				
Increment - Decrement of Idle Speed				
Power Steering Electric Pump Unit				
Read Air Conditioning Configuration				
Read EGR Type				
Read Injection type				
Read Inlet Type				
Read number of cylinders				
Read Swirl Flap Option				
Read Thermoplunger Option				
Thermoplunger				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BOSCH EDC 16 C3 (MEGANE II)	✓	✓	✓	✓
Special Functions				
Air conditioning				
Cruise Control				
ECU replacement				
EGR Adaptive				
Enter Injector Codes				
Erase Programmed Values				
Speed Limiter				
Water In Diesel Detector				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BOSCH EDC 16 C3 (SCENIC II)	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Egr Adaptives				
Enter Injector Codes				
Erase Programmed Values				
Water in Diesel Sensor				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BOSCH EDC15 VM+ SOFT C2	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Power Steering Electric Pump Unit				
Thermoplunger				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
BOSCH MONOMOTRONIC MA 1.7	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Injection Prohibition</i>				
<i>Learned Parameters Reset</i>				
<i>Unlock Injectors</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
BOSCH MOTRONIC M 4.4.2	👤	👤	✓	👤
BOSCH MOTRONIC MP 7.0	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Injection System Disabling</i>				
<i>Injection System Enabling</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
BOSCH MSA 15 soft CA vdiag 04	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Faults Test</i>				
<i>Idle Speed Decrease</i>				
<i>Idle Speed Increase</i>				
<i>Power Assisted Steering</i>				
<i>Thermoplunger</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM 1.2 (CLIO III)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>ECU replacement</i>				
<i>EGR Adaptative</i>				
<i>Erase Programmed Values</i>				
<i>Injector programming</i>				
<i>Lock Injector Control</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM1.2 L4C Vdiag 08 X90-L4C-08	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Egr Adaptives</i>				
<i>Enter Injector Codes</i>				
<i>Lock Injector Control</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Programmed Values</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM1.2 L4C Vdiag08 X65 X76 X90	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Control unit replacement</i>				
<i>Cylinder 1 Injector</i>				
<i>Cylinder 2 Injector</i>				
<i>Cylinder 3 Injector</i>				
<i>Cylinder 4 Injector</i>				
<i>Egr Adaptives</i>				
<i>Engine Parameter Adaptives</i>				
<i>Enter Injectors Calibration Data</i>				
<i>Injection Prohibition</i>				
<i>Vehicle Function Programming</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM1.2 L4D Vdiag50 J77 X84 X85-4D8-50	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Configurations</i>				
<i>Egr Adaptives</i>				
<i>Enter Injector Codes</i>				
<i>Lock Injector Control</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM1.2 L4D Vdiag54 X61-L4DB-54	✓	✓	✓	✓

<b>Special Functions</b>
Configurations
Cruise Control
Cruise Control/Speed Limiter
Egr Adaptives
Enter Injector Codes
Lock Injector Control
Mass Air Flow meter
Pressure Regulation Adaptives
Refilling New Pump Body
Save / Write Data Computer Replacement
Speed Limiter
Van Idle Speed Change
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM3.4_4B_Vdiag45_X61-4B-45	✓	✓	✓	✓

<b>Special Functions</b>
Adaptive rail pressure sensor
Air chain programming
Air Intake Flap Programming
Camshaft sensor programming
Cruise Control Function
Cruise Control/Speed Limiter
Cruise Control/Speed Limiter Buttons
EGR valve learn
Engine Adaptatives
Enter Injector Codes.
Exhaust Nozzle Circuit
Flywheel Target Programming
Fuel Flow Regulator
Fuel Supply Prevention
Injection Protection
Oil Change Interval (OCS): Dilution
Oil Change Interval (OCS): Oxidation
Particle Filter Pressure Relative Sensor
Pressure Regulation Adaptives
Speed limit function
Speed Limiter
Stop Fuel Supply Prevention
Van Idle Speed Change
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DCM34_34_Vdiag44_X95-34-44	✓	✓	✓	✓

<b>Special Functions</b>
Camshaft sensor programming
Cruise Control Function
Cruise Control/Speed Limiter Buttons
Cruise ctrl/Spd limiter
End learning Cruise Control / Speed Limiter
Engine Adaptatives
Enter Injector Codes
Flywheel Target Programming
Fuel Supply Prevention
Injection Protection
Inyection Adaptatives
Learning Control/Speed Limiter Buttons
Pressure Regulation Adaptives
Speed Limiter Function
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DDCR (MEGANE II)	✓	✓	✓	✓

<b>Special Functions</b>
ECU replacement
EGR Adaptative
Enter Injector Codes
Erase Programmed Values
GearBox Type
Pressure Regulation Adaptives
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DDCR BE Vdiag14 X65 X76	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Climatization</i>				
<i>Cruise ctrl/Spd limiter</i>				
<i>Cylinder 1 Injector</i>				
<i>Cylinder 2 Injector</i>				
<i>Cylinder 3 Injector</i>				
<i>Cylinder 4 Injector</i>				
<i>Decrement Idle Speed</i>				
<i>Egr Adaptives</i>				
<i>Engine Parameter Adaptives</i>				
<i>Gearbox type</i>				
<i>High Pressure Circuit Leak Test</i>				
<i>Increment Of Idle Speed</i>				
<i>Injection Prohibition</i>				
<i>Learning vehicle functions</i>				
<i>Power Steering Electric Pump Unit</i>				
<i>Prevention Of Electrical Consumers</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Static/Autoconfiguration Test</i>				
<i>Thermoplunger</i>				
<i>Write of VIN</i>				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DDCR BE Vdiag18 X65 X76	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Cruise ctrl/Spd limiter</i>				
<i>Cylinder 1 Injector</i>				
<i>Cylinder 2 Injector</i>				
<i>Cylinder 3 Injector</i>				
<i>Cylinder 4 Injector</i>				
<i>Decrement Idle Speed</i>				
<i>Egr Adaptives</i>				
<i>Engine Parameter Adaptives</i>				
<i>Gearbox type</i>				
<i>High Pressure Circuit Leak Test</i>				
<i>Increment Of Idle Speed</i>				
<i>Injection Prohibition</i>				
<i>Learning vehicle functions</i>				
<i>Power Steering Electric Pump Unit</i>				
<i>Prevention Of Electrical Consumers</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Static/Autoconfiguration Test</i>				
<i>Thermoplungers</i>				
<i>Write Vin</i>				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DDCR BE Vdiag48 X84-001-48	✓	✓	✓	✓
<i>Special Functions</i>				
<i>ECU replacement</i>				
<i>Egr Adaptives</i>				
<i>Enter Injector Codes</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Programmed Values</i>				
<i>Write of VIN</i>				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
DDCR-BE-14	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Climatization</i>				
<i>EGR Adaptative</i>				
<i>Engine Parameter Adaptives</i>				
<i>Enter Injector Codes</i>				
<i>Gearbox type</i>				
<i>Injection Prohibition</i>				
<i>Number Of Thermoplungers</i>				
<i>Power Steering Electric Pump Unit</i>				
<i>Prevention Of Electrical Consumers</i>				
<i>Save / Write Data Computer Replacement</i>				

Vehicle Function Programming				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DELPHI LVCR	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Cruise Control / Speed Limiter</i>				
<i>Enter Injectors Calibration Data</i>				
<i>Gear Box Type</i>				
<i>High Pressure Circuit Leak Test</i>				
<i>Idle Speed Decrease</i>				
<i>Idle Speed Increase</i>				
<i>Injection System Disabling</i>				
<i>Learned Parameters Reset</i>				
<i>Load disablement</i>				
<i>Power Steering Electric Pump Unit</i>				
<i>Reset Auto-Adaptive Values</i>				
<i>Static / Autoconfiguration Test</i>				
<i>Thermoplunger</i>				
<i>Write of VIN</i>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPCN LUCAS	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Control Unit Programming without Air Conditioner</i>				
<i>ECU Programming with Air Conditioner</i>				
<i>ECU Programming with Power Steering</i>				
<i>ECU Programming without Power Steering</i>				
<i>Injection System Disabling</i>				
<i>Injection System Enabling</i>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPCN LUCAS 1+	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Control Unit Programming without Air Conditioner</i>				
<i>ECU Programming with Air Conditioner</i>				
<i>ECU Programming with Power Steering</i>				
<i>ECU Programming without Power Steering</i>				
<i>FULL THROTTLE POSITION LEARNING</i>				
<i>Injection System Disabling</i>				
<i>Injection System Enabling</i>				
<i>THROTTLE PEDAL ADJUSTMENT</i>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
DPCN LUCAS 1+RC	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Control Unit Programming without Air Conditioner</i>				
<i>ECU Programming with Air Conditioner</i>				
<i>ECU Programming with Power Steering</i>				
<i>ECU Programming without Power Steering</i>				
<i>FULL THROTTLE POSITION LEARNING</i>				
<i>Injection System Disabling</i>				
<i>Injection System Enabling</i>				
<i>THROTTLE PEDAL ADJUSTMENT</i>				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
EDC16C3_C1_Vd5C-C1-5C	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Climatization</i>				
<i>Configurations</i>				
<i>Cruise Control</i>				
<i>Ecu Memory</i>				
<i>Enter Injector Codes</i>				
<i>Learned Parameters Reset</i>				
<i>Regeneration of the Particulate Emission Filter</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Speed Limiter</i>				
<i>Thermoplungers</i>				
<i>Water In Diesel Detector</i>				
<i>Write Vin</i>				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS 3110 X95-D9-44	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Adaptive ignition coil</i>				
<i>Camshaft sensor programming</i>				
<i>Cruise Control Function</i>				
<i>Cruise Control/Speed Limiter</i>				
<i>Cruise Control/Speed Limiter Buttons</i>				
<i>Engine Adaptatives</i>				
<i>Fuel Supply Prevention</i>				
<i>Injection Protection</i>				
<i>Learning Control/Speed Limiter Buttons</i>				
<i>Oil Change Interval (OCS): Oxidation</i>				
<i>Richness regulation learning</i>				
<i>Sensor chopped learning</i>				
<i>Speed limit function</i>				
<i>Start Obd Test: Catalytic Converter</i>				
<i>Start Obd Test: O2 Sensors</i>				
<i>Throttle end stop programming</i>				
<i>Writing V.I.N.</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS 3132 E1 VDIAG 15	✓	✓	✓	✓
<i>Special Functions</i>				
<i>ABS -&gt; Injection Interface</i>				
<i>AC Cold Loop in the Injection</i>				
<i>Air Conditioning</i>				
<i>Brake Switch Normally Open</i>				
<i>Camshaft Offset</i>				
<i>Downstream Oxygen Sensor</i>				
<i>Engine Immobiliser</i>				
<i>Fan Control, Engine Running</i>				
<i>Fixed Displacement Compressor</i>				
<i>Gear Change Warning Light</i>				
<i>GearBox Type</i>				
<i>Heated Windscreen</i>				
<i>OBD Light</i>				
<i>Pencil Type Ignition Coil</i>				
<i>Programming Reinitialisation</i>				
<i>Reduced Flow Fuel Pump</i>				
<i>Upstream Oxygen Sensor</i>				
<i>Vehicle Speed Connection Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS 3132 VDIAG 11	✓	✓	✓	✓
<i>Special Functions</i>				
<i>AC Cold Loop in the Injection</i>				
<i>Camshaft Offset</i>				
<i>Downstream Oxygen Sensor</i>				
<i>Fan Control, Engine Running</i>				
<i>Fixed Displacement Compresor</i>				
<i>Gear Change Warning Light</i>				
<i>GearBox Type</i>				
<i>Heated Windscreen</i>				
<i>Injection -&gt; LPG connection</i>				
<i>Learned Parameters Reset</i>				
<i>Pencil Type Ignition Coil</i>				
<i>Programming Reinitialisation</i>				
<i>Read Air Conditioning Configuration</i>				
<i>Reduced Fuel Mode Request</i>				
<i>Thermoplunger Management</i>				
<i>Upstream Oxygen Sensor</i>				
<i>Vehicle Speed Connection Via The CAN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS 3132 VDIAG 15	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Learned Parameters Reset</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS3130-EB400-04	✓	✓	✓	✓

<b>Special Functions</b>
Abs -> Injection Interface
AC Cold Loop In The Injection
Ac Strategy For Small Engines
Air Temperature Sensor Type A
Brake Switch Normally Open
Catalytic Converter Diag Obd Sequencer
Control Of Air Con. Compressor And Fan Unit
Cylinder 1 Recognition
Fan Control, Engine Running
Fault codes lecture
Learned Parameters Reset
Misfire Diag Obd Sequencer
Misfire Obd Light Control
OBD Warning Lamp
Pencil Type Ignition Coil
Read Configuration: Air Conditioning
Reduced Flow Fuel Pump
Sensors Diag Obd Sequencer
Severity 1 Warning Light
Severity Led 2
Terminal "DF"
Vehicle Speed Connection Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS3132 L90 soft E1 vdiag 15-E1-15	✓	✓	✓	✓

<b>Special Functions</b>
ABS -> Injection Interface
AC Cold Loop in the Injection
Air Conditioning
Brake Switch Normally Open
Camshaft Offset
Downstream Oxygen Sensor
Engine Immobiliser
Fan Control, Engine Running
Fixed Displacement Compressor
Gear Change Warning Light
GearBox Type
Heated Windscreen
OBD Light
Pencil Type Ignition Coil
Programming Reinitialisation
Reduced Flow Fuel Pump
Upstream Oxygen Sensor
Vehicle Speed Connection Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
EMS3134 L90-EA600-08	✓	✓	✓	✓

<b>Special Functions</b>
AC -> Injection Connection Via The Can
AC Cold Loop In The Injection
Air Temperature Sensor Type A
Camshaft Offset
Downstream Oxygen Sensor
Fixed Displacement Compressor
Gearbox Type
Obd Light
Passenger Compartment Heating Resistor
Pencil Type Ignition Coil
Programming Reinitialisation
Read Oxygen Sensor Option
Reduced Flow Fuel Pump
Severity Led 2
Terminal "DF"
Thermoplunger Management
Upstream Oxygen Sensor
Vehicle Speed Connection Via The Can
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJ_TR25_H45-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Adaptive Value - A/F Ratio</i>				
<i>Idle Air Volume Learning - Factory Mode</i>				
<i>Idle Air Volume Learning - Service Mode</i>				
<i>Ignition Timing Adjustment</i>				
<i>Increment Of Idle Speed</i>				
<i>Write Vin</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJ_V40_H4J_X95-29-44	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Cruise Control Function</i>				
<i>Cruise Control/Speed Limiter Buttons</i>				
<i>End learning Cruise Control / Speed Limiter</i>				
<i>Engine Adaptatives</i>				
<i>Flywheel Target Programming</i>				
<i>Fuel Supply Prevention</i>				
<i>Injection Protection</i>				
<i>Learning Control/Speed Limiter Buttons</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Speed Limiter Function</i>				
<i>Start Obd Test: Catalytic Converter</i>				
<i>Start Obd Test: O2 Sensors</i>				
<i>Throttle stop learning</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJ_V40_K4M_X95-27-44	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Camshaft Phase Shifter In Defect Mode</i>				
<i>Configurations</i>				
<i>Engine Immobiliser Circuit</i>				
<i>Fuel Supply Prevention</i>				
<i>Injection Protection</i>				
<i>Start Obd Test: Catalytic Converter</i>				
<i>Start Obd Test: O2 Sensors</i>				
<i>Stop Fuel Supply Prevention</i>				
<i>Throttle stop learning</i>				
<i>Vehicle Function Programming</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION 5NR 65PHII MUX SOFT 25 OBD	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Catalytic Converter Test</i>				
<i>Misfiring Test</i>				
<i>O2 Sensor Test</i>				
<i>Programming Reinitialisation</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION BOSCH EDC15	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air conditioning</i>				
<i>Engine Idle Speed</i>				
<i>Thermoplunger</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION DCM1.2 L4D Vdiag48 J77 X84 X85-04D-48	✓	✓	✓	✓
<i>Special Functions</i>				
<i>ECU replacement</i>				
<i>Egr Adaptives</i>				
<i>Enter Injector Codes</i>				
<i>Lock Injector Control</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Programmed Values</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION DDCR-04D-44	✓	✓	✓	✓
<i>Special Functions</i>				

ECU replacement				
Egr Adaptives				
Enter Injector Codes.				
Lock Injector Control				
Pressure Regulation Adaptives				
Programmed Values				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION DENSO J81 ph1 - BF - O4	✓	✓	✓	✓
Special Functions				
Decrement Idle Speed				
Fuel Supply Prevention				
Increment of idle speed				
Programmed Values				
Stop Fuel Supply Prevention				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION DENSO X73 J81 - BF - OC	✓	✓	✓	✓
Special Functions				
Decrement Idle Speed				
Fuel Supply Prevention				
Increment of idle speed				
Programmed Values				
Stop Fuel Supply Prevention				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION DENSO X73ph1-BF-04	✓	✓	✓	✓
Special Functions				
Configurations				
Cruise control				
Decrement Idle Speed				
Fuel Supply Prevention				
Heating resistors				
Increment Of Idle Speed				
Speed restriction				
Stop Fuel Supply Prevention				
Thermoplungers				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC 15 C - Vdiag 18 VB0 - IMA	✓	✓	✓	✓
Special Functions				
Decrement Idle Speed				
ECU replacement				
Enter Injectors Calibration Data				
Increment of idle speed				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC 15C - Vd 18- X83 soft O12	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Decrement Idle Speed				
ECU replacement				
Increment of idle speed				
Thermoplunger				
Van Fast Idle Speed Decrease				
Van Fast Idle Speed Increase				
Van Specific Idle Speed				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC 15C - Vd 19- X83	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Decrement Idle Speed				
Increment Of Idle Speed				
Save / Write Data Computer Replacement				
Thermoplunger				
Van Fast Idle Speed				
Write Vin				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC 15C - Vd18 VB0-IMA X70ph2	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Decrement Idle Speed</i>				
<i>ECU replacement</i>				
<i>Enter Injectors Calibration Data</i>				
<i>Increment of idle speed</i>				
<i>Passenger Compartment Heating Resistor</i>				
<i>Van Fast Idle Speed Decrease</i>				
<i>Van Fast Idle Speed Increase</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC 15C - Vd19 VB3-IMA X70ph2	✓	👤	✓	✓
<i>Special Functions</i>				
<i>Climatization</i>				
<i>Decrement Idle Speed</i>				
<i>Increment Of Idle Speed</i>				
<i>Maximum Permissible Speed</i>				
<i>Passenger Compartment Heating Resistor</i>				
<i>Speed Limiter</i>				
<i>Speed limiter function</i>				
<i>Van Fast Idle Speed Decrease</i>				
<i>Van Fast Idle Speed Increase</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC 15C - Vd19 VB3 - IMA X70ph1	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Decrement Idle Speed</i>				
<i>ECU replacement</i>				
<i>EGR Valve Programming</i>				
<i>Engine Adaptatives</i>				
<i>Enter Injectors Calibration Data</i>				
<i>Increment of idle speed</i>				
<i>Passenger Compartment Heating Resistor</i>				
<i>Van Fast Idle Speed Decrease</i>				
<i>Van Fast Idle Speed Increase</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC 15C - Vdiag 08 - MASTER	✓	✓	✓	👤
INJECTION EDC 15C - Vdiag 19 VB0- IMA	✓	✓	✓	👤
INJECTION EDC 15C - Vdiag08-ESPACE	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Cruise Control</i>				
<i>Decrement Idle Speed</i>				
<i>Increment Of Idle Speed</i>				
<i>Swirl Flap</i>				
<i>Thermoplunger</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC 15C - Vdiag08-MEGANE	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air conditioning</i>				
<i>Decrement Idle Speed</i>				
<i>Increment of idle speed</i>				
<i>Thermoplunger</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC 15C - Vdiag08-SCENIC	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Decrement Idle Speed</i>				
<i>Increment of idle speed</i>				
<i>Thermoplunger</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC15 X83II ph2-0012-19	✓	✓	✓	✓

Special Functions				
Climatization				
Decrement Idle Speed				
Egr Adaptives				
Engine Adaptatives				
Gearbox Type				
Increment Of Idle Speed				
Save / Write Data Computer Replacement				
Thermoplungers				
Vehicle Parameter				
Water In Diesel Detector				
With Swirl Flap				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC15-00 C3-0C	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Decrement Idle Speed				
GearBox Type				
Increment of idle speed				
Read Swirl Flap Option				
Thermoplunger				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC15-9BC1-10	✓	✓	✓	✓
Special Functions				
Climatization				
ECU replacement				
Enter Injector Codes				
Increment - Decrement of Idle Speed				
Read Swirl Flap Option				
Thermoplunger				
Type of gearbox				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC15C - Vdiag 14 VA2 - IMA	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Decrement Idle Speed				
ECU replacement				
EGR Valve Programming				
Engine Adaptatives				
Enter Injectors Calibration Data				
Increment of idle speed				
Passenger Compartment Heating Resistor				
Van Fast Idle Speed Decrease				
Van Fast Idle Speed Increase				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC15-VA2-14	✓	✓	✓	✓
Special Functions				
Air Conditioning				
ECU replacement				
EGR Adaptative				
Engine Adaptatives				
Enter Injector Codes				
GearBox Type				
Increment - Decrement of Idle Speed				
Read Swirl Flap Option				
Thermoplunger				
Water in Diesel				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC15-VB0-18	✓	✓	✓	✓
Special Functions				
Air Conditioning				
Decrement Idle Speed				

Enter Injector Codes				
Increment of idle speed				
Thermoplunger				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>INJECTION EDC15-VB2-18</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
Cylinder 1 injector code				
Cylinder 2 injector code				
Cylinder 3 injector code				
Cylinder 4 injector code				
EGR Adaptative				
Engine Adaptatives				
Enter Injector Codes				
Increment - Decrement of Idle Speed				
Thermoplunger				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>INJECTION EDC15-VC1-1D</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
Decrement Idle Speed				
Egr Adaptives				
Engine Adaptatives				
Increment Of Idle Speed				
Save / Write Data Computer Replacement				
Thermoplungers				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>INJECTION EDC15VM+ APV2</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
Power Steering Electric Pump Unit				
Thermoplunger				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>INJECTION EDC16 CP33 VDIAG 0C-00C4-0C</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
Cruise control				
Ecu Memory				
EGR Valve				
Enter Injector Codes				
Fuel Injectors				
Fuel Supply Prevention				
High Pressure Fuel Circuit Fault Finding				
Inlet Flap				
Oil Change Interval (OCS): Oxidation				
Programmed Values				
Save / Write Data Computer Replacement				
Speed Limiter				
Thermoplunger				
Van Idle Speed Change				
Water In Diesel Detector				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>INJECTION EDC16 CP33-C4-44 (250 Kbps)</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Climatization				
Cruise control				
Decrement Idle Speed				
Ecu Memory				
EGR Valve				
Enter Injector Codes				
Fast Speed Fan Relay Control				
Fuel Injectors				
Fuel Supply Prevention				

High Pressure Fuel Circuit Fault Finding
Increment Of Idle Speed
Inlet Flap
Programmed Values
Save / Write Data Computer Replacement
Slow Speed Fan Relay Control
Speed Limiter
Water In Diesel Detector
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC16 CP33-C4-44 (500 Kbps)	✓	✓	✓	✓

Special Functions
Climatization
Cruise control
Decrement Idle Speed
Ecu Memory
EGR Valve
Enter Injector Codes
Fuel Injectors
Fuel Supply Prevention
High Pressure Fuel Circuit Fault Finding
Immobiliser Code Programmed
Increment Of Idle Speed
Inlet Flap
Programmed Values
Save / Write Data Computer Replacement
Speed Limiter
Water In Diesel Detector
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC16 X70(Diag K)	✓	✓	✓	✓

Special Functions
Adaptives on EGR Valve Fault
Air Conditioning
Cruise Control
Engine Parameter Adaptives
Enter Injector Calibration Data
Fuel Supply Prevention
Passenger Compartment Heating Resistor
Save / Write Data Computer Replacement
Speed Limiter
Turbocharger type
Type of High Pressure Pump
Water In Diesel Detector
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC16 X70(Diag K)	✓	✓	✓	✓

Special Functions
Adaptives on EGR Valve Fault
Engine Parameter Adaptives
Fast Speed Fan Relay Control
Fuel Supply Prevention
Impact Detected By Injection Computer
Passenger Compartment Heating Resistor
Replacement of the injection ECU
Slow Speed Fan Relay Control
Using Injector Codes
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION EDC16 X84-VE3B-50	✓	✓	✓	✓

Special Functions
After control unit replacement without pisibility to save
After Particle Filter Regeneration With The Diag Tool.
After particle filter replacement
Air Conditioning
Cabin Filter Regeneration
Cruise Control
Ecu Memory

ECU replacement				
EGR Valve				
Enter Injector Codes				
Inlet Flap				
Programmed Values				
Speed Limiter				
Thermoplungers				
Water In Diesel Detector				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EDC16 X84-VE6-58	✓	✓	✓	✓
<b>Special Functions</b>				
After control unit replacement without pisibility to save				
AFTER PARTICLE FILTER REGENERATION WITH THE DIAG TOOL				
After particle filter replacement				
Climatization				
Cruise Control				
Ecu Memory				
ECU replacement				
EGR Valve				
Enter Injector Codes.				
Inlet Flap				
Programmed Values				
Regeneration of the Particulate Emission Filter				
Speed Limiter				
Thermoplunger				
Water In Diesel Detector				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EWR 20-V4Y-04	✓	✓	✓	✓
<b>Special Functions</b>				
Air Path Programming				
Decrement Idle Speed				
Increment of idle speed				
Programming Reinitialisation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION EWR 20-V4Y-08	✓	✓	✓	✓
<b>Special Functions</b>				
Air Path Programming				
Decrement Idle Speed				
Increment of idle speed				
Programming Reinitialisation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION ME 7.4.6-1300-04	✓	✓	✓	✓
<b>Special Functions</b>				
Configurations				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION MOTRONIC 7.0	✓	✓	✓	⊘
INJECTION MSA15 soft CD Vdiag 05	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning				
Decrement Idle Speed				
Increment of idle speed				
Power Assisted Steering				
Thermoplunger				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION MSA15 soft CD Vdiag 06	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning				
Decrement Idle Speed				
Increment of idle speed				
Power Assisted Steering				
Thermoplunger				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION MSA15 soft CD-CE Vdiag 04	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Decrement Idle Speed</i>				
<i>Increment of idle speed</i>				
<i>Power Assisted Steering</i>				
<i>Thermoplunger</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S2000 TURBO-A560-04	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Decrement Idle Speed</i>				
<i>Increment of idle speed</i>				
<i>Programming Reinitialisation</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S2000-00A3-0C	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Decrement Idle Speed</i>				
<i>Increment of idle speed</i>				
<i>Programming Reinitialisation</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S3000 85RS-AD8X-4C	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Camshaft Phase Shifter In Defect Mode</i>				
<i>Catalytic Converter Diag Obd Sequencer</i>				
<i>Climatization</i>				
<i>Cruise Control</i>				
<i>Downstream Oxygen Sensor</i>				
<i>Lock Injector Control</i>				
<i>Programmed Values</i>				
<i>Sensors Diag Obd Sequencer</i>				
<i>Speed Limiter</i>				
<i>Start Obd Test: Catalytic Converter</i>				
<i>Start Obd Test: O2 Sensors</i>				
<i>Trajectory Control</i>				
<i>Unlock Injector Control</i>				
<i>Upstream Oxygen Sensor</i>				
<i>Vehicle Speed Connection Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S3000 COMVVT-AD87-54	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Ac Air Heater Resistor Management</i>				
<i>Air conditioning</i>				
<i>Camshaft Offset</i>				
<i>Closure Brake Contact</i>				
<i>Controlled Coolant Thermostat</i>				
<i>Cruise Control</i>				
<i>Cylinder 1 Recognition</i>				
<i>Downstream oxygen sensor</i>				
<i>Electric Water Pump</i>				
<i>Gearbox Type</i>				
<i>Lock Injector Control</i>				
<i>Obd Warning Light Management</i>				
<i>Speed Limiter</i>				
<i>Trajectory Control</i>				
<i>Unlock Injector Control</i>				
<i>Upstream Oxygen Sensor</i>				
<i>Vehicle Speed Connection Type</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S3000 X61 AD.CX 5C-AD.CX-5C	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Ac Air Heater Resistor Management</i>				
<i>Air conditioning</i>				

Camshaft Offset
Closure Brake Contact
Configurations
Controlled Coolant Thermostat
Cruise Control
Cruise Control/Speed Limiter
Cylinder 1 Recognition
Downstream Oxygen Sensor
Electric Water Pump
Gearbox Type
Lock Injector Control
Motorised Throttle In Downgraded Mode
Obd Warning Light Management
Speed Limiter
Trajectory Control
Unlock Injector Control
Upstream Oxygen Sensor
Vehicle Speed Connection Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S3000 X91-26-44	✓	✓	✓	✓

Special Functions
Brake Assist Vacuum Pump
Camshaft Offset
Camshaft Phase Shifter In Defect Mode
Catalytic Converter Diag Obd Sequencer
Cc/Sl Deactivation By Driver Action
Cruise Control Function
Cruise Control/Speed Limiter
Cruise Control/Speed Limiter Buttons
Engine Immobiliser Circuit
Injection Protection
Programmed Values
Programming of the throttle stops
Sensors Diag Obd Sequencer
Speed limit function
Start Obd Test: Catalytic Converter
Start Obd Test: O2 Sensors
Vehicle Function Programming
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S3000-AD70-48	✓	✓	✓	✓

Special Functions
Lock Injector Control
Programmed Values
Unlock Injector Control
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION S3000-AD80-4C	✓	✓	✓	✓

Special Functions
Ac Air Heater Resistor Management
Camshaft Offset
Climatization
Closure Brake Contact
Controlled Coolant Thermostat
Cruise Control
Cylinder 1 Recognition
Downstream oxygen sensor
Electric Water Pump
Gearbox Type
Lock Injector Control
Obd Warning Light Management
Programming
Speed Limiter
Trajectory Control
Unlock Injector Control
Upstream oxygen sensor
Vehicle Speed Connection Type
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION SID 301 X61-00B1-48	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Air Conditioning</i>				
<i>Cruise Control</i>				
<i>Egr Adaptives</i>				
<i>Enter Vin Code</i>				
<i>Oil Change Interval (OCS): Oxidation</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Programming Reinitialisation</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Speed Limiter</i>				
<i>Water In Diesel Detector</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION SID304 -B2-45	✓	✓	✓	✓
<i>Special Functions</i>				
<i>ECU replacement</i>				
<i>Write of VIN</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION SID304 X61-00B2-4D	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Climatization</i>				
<i>Cruise Control</i>				
<i>Egr Adaptives</i>				
<i>Enter Vin Code</i>				
<i>Gearbox Type</i>				
<i>Oil Change Interval (OCS): Dilution</i>				
<i>Oil Change Interval (OCS): Oxidation</i>				
<i>Particle Filter Adaptives</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Programming Reinitialisation</i>				
<i>Save / Write Data Computer Replacement</i>				
<i>Speed Limiter</i>				
<i>Van Idle Speed Change</i>				
<i>Water In Diesel Detector</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION SIM 32-00D3-44	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Ac Air Heater Resistor Management</i>				
<i>Air Conditioning</i>				
<i>Configurations</i>				
<i>Cruise control</i>				
<i>Downstream oxygen sensor</i>				
<i>Gearbox type</i>				
<i>Lock Injector Control</i>				
<i>Obd Warning Light Management</i>				
<i>Speed Limiter</i>				
<i>Start Obd Test: Catalytic Converter</i>				
<i>Start Obd Test: O2 Sensors</i>				
<i>Trajectory Control</i>				
<i>Unlock Injector Control</i>				
<i>Upstream oxygen sensor</i>				
<i>Vehicle Speed Connection Type</i>				
<i>Writing V.I.N.</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION SIRIUS 35-0E06-04	✓	✓	✓	✓
<i>Special Functions</i>				
<i>AC Cold Loop in the Injection</i>				
<i>Automatic Transmission</i>				
<i>Clutch Switch</i>				
<i>Decrement Idle Speed</i>				
<i>Increment Of Idle Speed</i>				
<i>Learned Parameters Reset</i>				
<i>Misfire of Diagnostic Request</i>				
<i>Power Steering Pressure Switch</i>				
<i>Pressure Regulation Adaptives</i>				
<i>Request for OBD Light by AT</i>				
<i>Speed Limitation</i>				

Speed Regulation				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION SIRIUS 3H RE3 B00	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning				
Automatic Transmission				
Cruise control				
Decrement Idle Speed				
Increment of idle speed				
OBD Fault Memory Erasing				
Power Assisted Steering				
Programming Reinitialisation				
Thermoplunger				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION SIRIUS E1 VDIAG 08	✓	✓	✓	✓
<b>Special Functions</b>				
Learned Parameters Reset				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION V42 X90-2A-06	✓	✓	✓	✓
<b>Special Functions</b>				
Alcohol Level Prog.				
Engine Adaptatives				
Flywheel Target Programming				
Fuel Supply Prevention				
Injection Protection				
Oil Change Interval (OCS): Oxidation				
Richness regulation learning				
Save / Write Data Computer Replacement				
Start Obd Test: Catalytic Converter				
Start Obd Test: O2 Sensors				
Throttle end stop programming				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION WB56_63XX_\$44_M4R_X85-63XX-44	✓	✓	✓	✓
<b>Special Functions</b>				
Cruise control				
Learned Parameters Reset				
Lock Injector Control				
Speed Limiter				
Unlock Injector Control				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION X91 SID301 -RM2-44	✓	✓	✓	✓
<b>Special Functions</b>				
Cc/SI Deactivation By Driver Action				
Cruise Control Function				
Cruise Control/Speed Limiter				
Cruise Control/Speed Limiter Buttons				
Egr Adaptives				
Injection Protection				
Oil Change Interval (OCS): Oxidation				
Operational Safety RV				
Pressure Regulation Adaptives				
Programmed Values				
Save / Write Data Computer Replacement				
Speed monitoring information RV / LV				
Speed limit function				
Surveillance info. cruise control				
Vehicle Function Programming				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INJECTION_M9R_H45-WD2-6C	✓	✓	✓	✓
<b>Special Functions</b>				
After control unit replacement without pisibility to save				
After Particle Filter Regeneration With The Diag Tool.				
After particle filter replacement				

Air Conditioning
Cabin Filter Regeneration
Cruise Control
Cruise Control/Speed Limiter Buttons
Ecu Memory
EGR Valve
Enter Injector Codes
Fuel Injectors
Fuel Supply Prevention
High Pressure Fuel Circuit Fault Finding
Inlet Flap
Programmed Values
Save / Write Data Computer Replacement
Speed Limiter
Stop Fuel Supply Prevention
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
INJECTION_M9R_X91-WD2-64	✓	✓	✓	✓

<b>Special Functions</b>
ECU replacement
Fuel Supply Prevention
Learned Parameters Reset
Stop Fuel Supply Prevention
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
K9K816 X61 K9K896 898 H79 VD65	✓	✓	✓	✓

<b>Special Functions</b>
Adaptives After Regeneration Cabin Filter
Adaptives After Replacing Cabin Filter
Air Intake Flap Programming
Cruise Control Function
Cruise Control/Speed Limiter Buttons
EGR valve learning
Engine Adaptatives
Enter Injector Codes
Exhaust Nozzle Circuit
Fuel Supply Prevention
Oil Change Interval (OCS): Dilution
Oil Change Interval (OCS): Oxidation
Particle Filter Pressure Relative Sensor
Pressure Regulation Adaptives
Rail Pressure Loop Variation
Regeneration of the Particulate Emission Filter
Save / Write Data Computer Replacement
Speed limit function
Stop Fuel Supply Prevention
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
LUCAS DCU 3R Vdiag 9	✓	✓	✓	✓

<b>Special Functions</b>
Air Conditioner Computer
Air Conditioning
By Engine Management Cold Loop
Cruise Control
Diesel Flow Limitation
EGR Electrovalve
Gear Box Type
Idle speed regulation
Power Assisted Steering
Preheating Prevention
Stop Pre - Heating Prevention
Vehicle Function Programming

ECU	Trouble Codes	Live Data	Actuators	Special Functions
LVCR DM X65 ph2	✓	✓	✓	✓

<b>Special Functions</b>
Climatization
Cruise Control / Speed Limiter
Decrement Idle Speed

ECU replacement				
Egr Adaptives				
Engine Parameter Adaptives				
Enter Injector Calibration Data				
Gearbox Type				
High Pressure Circuit Leak Test				
Increment Of Idle Speed				
Injection Prohibition				
Power Steering Electric Pump Unit				
Prevention Of Electrical Consumers				
Static/Autoconfiguration Test				
Thermoplunger				
Vehicle Function Programming				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MARELLI 5NR SOFT25 (NON MUX)	✓	✓	✓	✓
<i>Special Functions</i>				
Catalytic Converter Test				
Fuel System Test				
Learned Parameters Reset				
Misfiring Test				
O2 Sensor Test				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MARELLI 5NR X06-X65 SOFT 24-25 OBD	✓	✓	✓	✓
<i>Special Functions</i>				
Catalytic Converter Test				
Fuel System Test				
Misfiring Test				
O2 Sensor Test				
Programming Reinitialisation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MARELLI IAW 5NR	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
Learned Parameters Reset				
Power Steering				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MARELLI IAW 6R	✓	✓	✓	👤
MARELLI IAW G8	✓	✓	✓	🚫
MARELLI SFR 200	✓	✓	✓	🚫
ME 7.4.6 TWR	✓	✓	✓	✓
<i>Special Functions</i>				
Programming Reinitialisation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ME 7.4.6 TWR L7X762	✓	✓	✓	✓
<i>Special Functions</i>				
Programming Reinitialisation				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MM EGR X70	✓	✓	👤	👤
MOTRONIC ME 7.4.6	✓	✓	✓	✓
<i>Special Functions</i>				
Learned Parameters Reset				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
MSA15 soft CD-CE Vdiag 05	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
Atmospheric / Turbo Engine				
Cruise Control				
Decrement Idle Speed				
EGR Type				
Flow Regulation Type				
GearBox Type				
Increment of idle speed				
Injection Type				
Number of Cylinders				

Power Assisted Steering				
Read Pas Unit Option				
Thermoplunger				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
S2000 - A3 60 - X65ph2	✓	✓	✓	✓
<b>Special Functions</b>				
Decrement Idle Speed				
Increment Of Idle Speed				
Learned Parameters Reset				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
S3000 AD CAN 1 X84 FLEXFUEL-AD90-50 INJECTION	✓	✓	✓	✓
<b>Special Functions</b>				
AC Cold Loop in the Injection				
Cruise Control				
Cylinder 1 Recognition				
Erase Programmed Values				
Lock Injector Control				
Speed Limiter				
Unlock Injector Control				
Upstream Oxygen Sensor				
Vehicle Speed Connection Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SAGEM S2000	✓	✓	✓	✓
<b>Special Functions</b>				
Idle Speed Decrease				
Idle Speed Increase				
Learned Parameters Reset				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SAGEM S3000 (MEGANE II)	✓	✓	✓	✓
<b>Special Functions</b>				
Air conditioner pressure signal				
Air Conditioning				
Catalytic Converter Diag OBD Sequencer				
Cylinder 1 Recognition				
Downstream Oxygen Sensor				
Erase Programmed Values				
GearBox Type				
Heating Resistor				
Lock Injector Control				
Misfire Diag OBD Sequencer				
OBD Warning Lamp				
Sensors Diag OBD Sequencer				
Traction Control				
Unlock Injector Control				
Upstream Oxygen Sensor				
Vehicle Speed Connection Type				
Water pump				
Wire Closing Brake Switch				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SAGEM S3000 (MODUS)	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning				
Air Conditioning Pressure Signal Management				
Air Pump				
Camshaft Phase Shifter In Defect Mode				
Catalytic Converter Diag OBD Sequencer				
Controlled Coolant Thermostat				
Cylinder 1 Recognition				
Downstream Oxygen Sensor				
Erase Programmed Values				
GearBox Type				
Heating Resistor				
Lock Injector Control				

Misfire Diag OBD Sequencer				
OBD Warning Light Management				
Sensors Diag OBD Sequencer				
Traction Control				
Unlock Injector Control				
Upstream Oxygen Sensor				
Vehicle Speed Connection Type				
Wire Closing Brake Switch				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SAGEM TPP EGR	✓	✓	✓	✓
<i>Special Functions</i>				
With Air Con / Without Heated Windscreen				
With Air Conditioning / With Heated Windscreen				
Without Air Con / With Heated Windscreen				
Without Air Con. / Without Heated Windscreen				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SAGEM TPP EGR X56	✓	✓	✓	✓
<i>Special Functions</i>				
Air Conditioning				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SID305_83_Vdiag44_X95-83-44	✓	✓	⊘	✓
<i>Special Functions</i>				
Cruise Control Function				
Cruise Control/Speed Limiter				
Cruise Control/Speed Limiter Buttons				
End learning Cruise Control / Speed Limiter				
Engine Adaptatives				
Fuel Supply Prevention				
Injection Protection				
Learning Control/Speed Limiter Buttons				
Oil Change Interval (OCS): Dilution				
Oil Change Interval (OCS): Oxidation				
Pressure Regulation Adaptives				
Save / Write Data Computer Replacement				
Speed limit function				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SIEMENS FENIX 1B (A)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (B)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (C)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (D)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (E)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (F - G)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (H)	✓	✓	⊘	⊘
SIEMENS FENIX 1B (I)	✓	✓	⊘	⊘
SIEMENS FENIX 3B (J)	✓	✓	⊘	⊘
SIEMENS FENIX 3B (K)	✓	🔧	⊘	⊘
SIEMENS FENIX 3B (L)	✓	✓	⊘	⊘
SIEMENS FENIX 3B (M)	✓	✓	⊘	⊘
SIEMENS FENIX 3B (N)	✓	✓	⊘	⊘
SIEMENS FENIX 5	✓	✓	✓	⊘
SIEMENS SAFIR	✓	✓	✓	⊘
SIEMENS SID 301 (CLIO III)	✓	✓	✓	✓
<i>Special Functions</i>				
Climatization				
Cruise control				
ECU replacement				
Egr Adaptives				
Erase Programmed Values				
Learned Parameters Reset				
Pressure Regulation Adaptives				
Speed Limiter				
Water In Diesel Detector				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SIEMENS SIRIUS 32 (CLIO III)	✓	✓	✓	✓

Special Functions				
AC Air Heater Resistor Management				
Air Conditioning				
Downstream Oxygen Sensor				
Erase Programmed Values				
GearBox Type				
Lock Injector Control				
OBD Warning Lamp				
Traction Control				
Unlock Injector Control				
Upstream Oxygen Sensor				
Vehicle Speed Connection Type				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
SIEMENS SIRIUS 32 E1	✓	✓	✓	✓
Special Functions				
AC Cold Loop in the Injection				
Camshaft Offset				
Downstream Oxygen Sensor				
Electric Windshield Wiper				
Fan Control, Engine Running				
Fixed Displacement Compresor				
Gear Box Type				
Gear Change Warning Light				
Injection <-> Air Conditioning Connections				
Injection -> LPG connection				
Learned Parameters Reset				
Pencil Type Ignition Coil				
Read Air Conditioning Configuration				
Reduced Flow Fuel Pump				
Thermoplunger Management				
Upstream Oxygen Sensor				
Vehicle Speed Connection Via The CAN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
SIEMENS SIRIUS 32_RD420	✓	✓	✓	✓
Special Functions				
Climatization				
Decrement Idle Speed				
Downstream Oxygen Sensor				
GearBox Type				
Increment Of Idle Speed				
Injection <-> Air Conditioning Connections				
Learned Parameters Reset				
Thermoplunger Management				
Trajectory Control				
Upstream Oxygen Sensor				
Vehicle Speed Connection Type				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
Sim 32_RD4A0_FLEX_FUEL_B2-D4A0-08	✓	✓	✓	✓
Special Functions				
Air Conditioning ----> Injection Connection				
Downstream oxygen sensor				
Learned Parameters Reset				
Writing V.I.N.				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
SIM32 D3.Cx \$50 X44 J77 X85-D3-50	✓	✓	✓	✓
Special Functions				
Camshaft Offset				
Catalytic Converter Diag Obd Sequencer				
Climatization				
Controlled Coolant Thermostat				
Cruise control				
Downstream oxygen sensor				
Gearbox Type				
Lock Injector Control				
Obd Warning Light Management				
Programmed Values				

Sensors Diag Obd Sequencer				
Speed Limiter				
Start Obd Test: Catalytic Converter				
Start Obd Test: O2 Sensors				
Trajectory Control				
Unlock Injector Control				
Upstream oxygen sensor				
Vehicle Speed Connection Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SIRIUS 34 E539	✓	✓	✓	✓
<b>Special Functions</b>				
AC -> Injection Connection Via The Can				
AC Cold Loop In The Injection				
Air Temperature Sensor Type A				
Camshaft Offset				
Catalytic Converter Obd Diagnostic				
Downstream oxygen sensor				
Fan Control, Engine Running				
Fixed Displacement Compressor				
Fuel Circuit Obd Diagnos.				
Gearbox type				
Learned Parameters Reset				
Misfire Obd Diagnostic				
Misfire Obd Light Control				
OBD Warning Lamp				
Oxygen Sensor Obd Diagn.				
Pencil Type Ignition Coil				
Read Oxygen Sensor Option				
Reduced Flow Fuel Pump				
Request For OBD Light On By Auto Gearbox				
Thermoplunger Management				
Upstream oxygen sensor				
Vehicle Speed Connection Via The CAN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SIRIUS 34 E553	✓	✓	✓	✓
<b>Special Functions</b>				
AC -> Injection Connection Via The Can				
AC Cold Loop in the Injection				
Air Temperature Sensor Type A				
Camshaft Offset				
Downstream Oxygen Sensor				
Fixed Displacement Compresor				
GearBox Type				
Learned Parameters Reset				
OBD Light				
Pencil Type Ignition Coil				
Read Oxygen Sensor Option				
Reduced Flow Fuel Pump				
Thermoplunger Management				
Upstream Oxygen Sensor				
Vehicle Speed Connection Via The CAN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SIRIUS 34 E565	✓	✓	✓	✓
<b>Special Functions</b>				
Learned Parameters Reset				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
SIRIUS 34 E5BO	✓	✓	✓	✓
<b>Special Functions</b>				
AC -> Injection Connection Via The Can				
AC Cold Loop In The Injection				
Air Temperature Sensor Type A				
Camshaft Offset				
Downstream Oxygen Sensor				
Fixed Displacement Compressor				
Gearbox Type				
Learned Parameters Reset				
Obd Light				

Pencil Type Ignition Coil
Read Oxygen Sensor Option
Reduced Flow Fuel Pump
Speed Limiter/Cruise Control Function
Thermoplunger Management
Upstream Oxygen Sensor
Vehicle Speed Connection Via The Can
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
SIRIUS E1 VDIAG 0C	✓	✓	✓	✓
<i>Special Functions</i>				
Programming Reinitialisation				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
SIRIUS E1 VDIAG 10	✓	✓	✓	✓
<i>Special Functions</i>				
AC Cold Loop in the Injection				
Camshaft Offset				
Downstream Oxygen Sensor				
Electric Windshield Wiper				
Fan Control, Engine Running				
Fixed Displacement Compresor				
Gear Box Type				
Gear Change Warning Light				
Injection <-> Air Conditioning Connections				
Injection -> LPG connection				
Learned Parameters Reset				
Pencil Type Ignition Coil				
Read Air Conditioning Configuration				
Reduced Flow Fuel Pump				
Thermoplunger Management				
Upstream Oxygen Sensor				
Vehicle Speed Connection Via The CAN				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
SIRIUS E3 VDIAG 08	✓	✓	✓	✓
<i>Special Functions</i>				
Automatic Transmission				
Climatization				
Cruise Control				
Engine Idle Speed				
Power Steering				
Programming				
Thermoplungers				

#### HANDS FREE KIT

ECU	Trouble Codes	Live Data	Actuators	Special Functions
HAND FREE PHONE 2-00077-04	✓	✓	✓	✓
<i>Special Functions</i>				
Computer Calibration And Operation				
Display Generation				
Hands-Free Kit Generation				
Language				
Radio Generation				
Radio Type				
Type of display				
Type Of Hands-Free Kit				
Vehicle Type				
Write Date Of Last After Sales Operation				
Writing V.I.N.				

#### IMMOBILIZER

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ANTIDEMARRAGE BII 3.7 (J66)	✓	✓	✓	✓
<i>Special Functions</i>				
Enter ACCESS CODE				
Programming With 1 Key				
Programming With 2 Keys				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
ANTIDEMARRAGE BII 3.9 (J66) ANT	👤	✓	✓	✓

Special Functions				
Enter Access Code				
Programming with 1 Key				
Programming With 2 Keys				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ANTIDEMARRAGE BII 4.1 (J66)	✓	✓	✓	✓
Special Functions				
Enter Access Code				
Programming With 1 Key				
Programming With 2 Keys				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ANTI-THEFT BIFUNCTION X56	✓	✓	✓	✓
Special Functions				
Diesel Engine Immobiliser				
Diesel Petrol Engine Immobiliser Without Coded Solenoid Valve				
Enter Access Code				
Programming with 1 Key				
Programming With 2 Keys				
With Infra Red Remote Control				
With Radio Frequency Remote Control				
With Timed Courtesy Light				
Without Timed Courtesy Light				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ANTI-THEFT CRYPTO KEY	✓	✓	✓	✓
Special Functions				
Diesel Engine Configuration				
Enter Access Code				
Petrol Engine Configuration				
Type 1 Unit				
Type 2 Unit				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ANTI-THEFT KEY	✓	✓	✓	✓
Special Functions				
After Market Repair Date				
Diesel Engine Configuration				
Enter Access Code				
Petrol Engine Configuration				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
ANTI-THEFT TIR 96	✓	✓	👤	👤
ANTI-THEFT TIR ISO 8	✓	✓	✓	✓
Special Functions				
Automatic Start Up Type				
Courtesy Light Extinguish Mode				
ECU Programming with Immobilizer Warning Lamp				
ECU Programming without Immobilizer Warning Lamp				
Engine Type				
Enter ACCESS CODE				
Timer Courtesy Light				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
BMT (N1/N2)(N5/N6) (IMMO)	✓	✓	✓	✓
Special Functions				
Calibration Finished				
Coded Diesel Solenoid				
Manual Code Entering				
Programming With 1 Key				
Programming With 2 Keys				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
INMOVILIZER BY UCH	👤	🚫	🚫	🚫
UCH x06 (IMMO)	✓	✓	✓	✓
Special Functions				
Key Programming				
Program Body Computer				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X06 Vdiag08 (ANT)	✓	✓	✓	✓
Special Functions				

Key programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65 (ANT)	✓	✓	✓	✓
Special Functions				
Extract PIN Code				
Key programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65 EXPORT (ANT)	✓	✓	✓	✓
Special Functions				
Key Programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65 EXPORT VDIAG08 (ANT)	✓	✓	✓	✓
Special Functions				
Ignition Keys Programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65 Mex HdG Vdiag08 type03 (ANT)	✓	✓	✓	✓
Special Functions				
Key programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH x65 MEXIQUE (CLIO II)(IMMOBILISER)	✓	✓	✓	✓
Special Functions				
Enter the VIN code				
Extract PIN Code				
Key Programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65 MEXIQUE HAUT DE GAMME (IMMO)	✓	✓	✓	✓
Special Functions				
Key programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65_05 (IMMO)	✓	✓	✓	✓
Special Functions				
Key programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65_09 (IMMO)	✓	✓	✓	✓
Special Functions				
Key Programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X65_0D (ANT)	✓	✓	✓	✓
Special Functions				
Extract PIN Code				
Key Programming				
Program Body Computer				
Writing V.I.N.				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X70ph2 (ANT)	✓	✓	✓	✓
Special Functions				
Key Programming				
Program Body Computer				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X76 (ANT) Mux	✓	✓	✓	✓
Special Functions				
Extract PIN Code				
Key programming				
Program Body Computer				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X76_0C (ANT) Mux	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Extract PIN Code</i>				
<i>Key Programming</i>				
<i>Program Body Computer</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X76_10 (ANT) Mux	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Extract PIN Code</i>				
<i>Program Body Computer</i>				
<i>Programming of key</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X83 ALARME(IMMO)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Key Programming</i>				
<i>Program Body Computer</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X83_04 (ANT)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Key Programming</i>				
<i>Program Body Computer</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH_X76G2005_V3.0 (ANT)	👤	✓	✓	✓
<i>Special Functions</i>				
<i>Extract PIN Code</i>				
<i>Key Programming</i>				
<i>Program Body Computer</i>				
INTERCONNECTION UNIT				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
BMT (N1/N2)(N5/N6) (BIC) CLIO	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Automatic Re-Locking</i>				
<i>Central Door Locking Button</i>				
<i>Configuration Interior Light Timer</i>				
<i>Illuminated Hazard Lamps Upon Impact</i>				
<i>Over-Speed Warning Function</i>				
<i>Programming 2<sup>o</sup> Plip Key</i>				
<i>Raid Function Authorisation</i>				
<i>Raid function inhibition</i>				
<i>Resynchronisation Of The Plip</i>				
<i>RF Function Configuration</i>				
<i>Running Lights</i>				
<i>Variable front wiper intermittent (frequency) configuration</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DECODER CONTROL UNIT (BMT)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Central Door Locking Button</i>				
<i>Configuration Interior Light Timer</i>				
<i>Programming 2<sup>o</sup> Plip Key</i>				
<i>Raid Function Authorisation</i>				
<i>Raid function inhibition</i>				
<i>RF Function Configuration</i>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
HABITACLE BII 3.7 (J661)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>ADAC</i>				
<i>Airbag</i>				
<i>Airbag Type</i>				
<i>Bii Type</i>				
<i>Control Panel Type</i>				
<i>Driving Type</i>				
<i>Engine Type</i>				
<i>Hazard Lamps Recall On Trf</i>				
<i>Radio Display</i>				

Rear Screen				
Vehicle Type				
With Tailgate Module				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
HABITACLE BII 3.9 (J66) / INSTRUMENT PANEL BII 3.9 (J66)	✓	✓	✓	✓
<b>Special Functions</b>				
ADAC				
Air Conditioning Type				
Airbag Type				
Control Panel Type				
Driving Type				
Engine Type				
Hazard Lamps Recall On Trf				
Oil level displayed 20sec				
Radio Display				
Rear Screen Type				
Tailgate Module				
Timer Courtesy Light				
Type of oil pressure switch				
Uch Type				
Vehicle Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
HABITACLE BII 4.1 (J66) / INSTRUMENT PANEL BII 4.1 (J66)	✓	✓	✓	✓
<b>Special Functions</b>				
ADAC				
Air Conditioning Type				
Airbag Type				
Bii Type				
Driving Type				
Engine Type				
Hazard Lamps Recall On Trf				
Oil level displayed 20sec				
Radio Display				
Rear Screen Type				
Vehicle Type				
With Tailgate Module				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCBIC - PASSENGER COMPARTMENT INTERCONNECTION UNIT	✓	✓	✓	✓
<b>Special Functions</b>				
Alarm Type Configuration: Europe				
Alarm Type Configuration: France				
Alarm Type Configuration: Germany				
Alarm Type Configuration: Switzerland				
Cabriolet Type Vehicle				
Calibrate				
Calibration Complete				
Other Type of Vehicle				
Programming - TIR Code Erase				
Programming - TIR Code Learning				
Programming Engine Type - Diesel with Codified Electrovalve				
Programming Engine Type - Petrol or Direct Diesel Injection				
Type 1 Engine Immobiliser Configuration				
Type 2 Engine Immobiliser Configuration				
Type 3 Engine Immobiliser Configuration				
With Alarm				
With Diesel Engine Immobiliser				
With Engine Immobiliser				
With Extreme Cold Fog Lights				
With Headlight Washers				
With Overspeed Warning				
With Running Lights				
With Timed Courtesy Light				
Without Alarm				
Without Diesel Engine Immobiliser				
Without Engine Immobiliser				
Without Extreme Cold Fog Lights				
Without Headlight Washers				
Without Overspeed Warning				
Without Running Lights				

Without Timed Courtesy Light				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH - PASSENGER COMPARTMENT CONTROL UNIT</b>	✓	✓	✓	✓
<i>Special Functions</i>				
All Types Except J64 4x4				
Automatic Doors Lock Programming - Authorization				
Automatic Doors Lock Programming - Disable				
Cabriolet E64				
ECU Programming with Immobilizer Type 1				
ECU Programming with Immobilizer Type 2				
Enter Access Code				
J64 4x4				
Keys Programming - Abandon Key Reallocation				
Keys Programming - End of Key Reallocation Validation				
Learning Blocking				
Non Cabriolet E64				
Programming Engine Type - Diesel with Codified Electrovalve				
Programming Engine Type - Petrol or Direct Diesel Injection				
Programming Immobilizer Function - Enable				
Programming Immobilizer Function - Prohibition				
Raid Function Authorisation				
Raid function inhibition				
RF Function Authorised				
RF Function Not Authorised				
With Alarm				
With Overspeed Warning				
With Rear Wiper				
With Rear Wiper Park				
With Timed Courtesy Light				
Without Alarm				
Without Overspeed Warning				
Without Rear Wiper				
Without Rear Wiper Park				
Without Timed Courtesy Light				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH 83 (04)</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Automatic Locking				
Clock				
Course ( Trajectory ) Control System				
Deadlocking				
Engine Type				
Instrument Panel Type				
Key Programming				
Original Equipment Alarm				
Program CAN configuration				
Seat Belt not Fastened Buzzer				
Second Fitting Alarm				
Speed Index				
Tachometer				
Timer Courtesy Light				
UCH Type				
Vehicle Speed Information				
Wiper Blade Inverted				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH 83 (ALA)</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Automatic re-locking				
Deadlocking				
Factory Fitted Alarm				
Key Programming				
Timer Courtesy Light				
UCH Type				
Wiper Blade Inverted				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH G2001 X70 Ph3-0006-10</b>	✓	✓	✓	✓

<b>Special Functions</b>
Airbag
Alarm Light
Automatic Locking When Driving
Automatic re-locking
Clock
Cruise Control / Speed Limiter
ESP
First breeding alarm
Gearbox type
Heated Rear Screen Configuration
Illuminate Hazard Lamps Upon Impact
Key Programming
Speedo Index
Tank capacity
Timed Lighting Supply
Timer Courtesy Light
Type of service
Uch Type
Vehicle speed information
Writing V.I.N.

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH G2001 X83llph2-0004-0C	✓	✓	✓	✓

<b>Special Functions</b>
Automatic Locking When Driving
Clock
Cruise Control/Speed Limiter
Deadlocking
Engine Type
Esp
Gearbox Type
Illuminate Hazard Lamps Upon Impact
Multiplex Network Configuration
Original fitment alarm
Overspeed Function - Arabia
Program Body Computer
Programming of key
Seat Belt Reminder Buzzer
Timed Lighting Supply
Timer Courtesy Light
Type of service
Vehicle Speed Information
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH G2005 X83ll ph2-0003-14	✓	✓	✓	✓

<b>Special Functions</b>
Day Running Lights
Instrument Panel Type
Key programming
Program Body Computer
VIN Code

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH H79 Trans CONTI OF 05 A	✓	✓	✓	✓

<b>Special Functions</b>
"Seat Belt Unfastened" Detection
Airbag
Automatic re-locking
Cadence variation by speed
Central Locking Button Type
Courtesy Light Timer
De-Ice Function
Engine type
Flashing Buzzer
Heated Rear Screen When Driving
Illuminate Hazard Lamps Upon Impact
Key block
Originally Fitted Perimetric Protection
Overspeed Alarm
Programming of keys

Radio Frequency Function				
Raid Function Authorisation By Diag				
Rear Fog Lights				
Rear Screen Wiper				
SDO				
Second Fitting Alarm				
Timer Courtesy Light				
Type of key				
Uch Type				
Vehicle Locked By Autolock When Driving Function				
Verrou Logiciel (Software Lock)				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH J77-1002-44	✓	✓	✓	✓
<b>Special Functions</b>				
3-Button Key				
Air Conditioning Type				
Blank Key				
Childproof Lock				
Daytime Running Lights				
Deadlocking				
DISCHARGE LAMP				
Driving Type				
External temperature sensor circuit				
Front Fog Lamp				
Hazard Warning Lights Illumination by ABS				
Headlight Washers				
Heating Resistor Type				
Key Allocated to the Vehicle				
Key Frequency (In MHz)				
Memory Key				
Memory Key Function				
New Vehicle Storage Mode				
New Vehicle Storage Mode Deactivation				
Rain/Light Sensor				
Selective Opening of Doors				
Source Of Action Before Next - Last Action				
Source Of Last Opening Element Action				
Source Of Next - Last Door Action				
Tailgate				
Windscreen Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH trans 6_1 L35 HDG BURSA-522-08	✓	✓	✓	✓
<b>Special Functions</b>				
Erase Computer Memory				
Flashing Buzzer				
Key Programming				
Uch Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH trans 6_1 L35 HDG CORDOBA-522-08	✓	✓	✓	✓
<b>Special Functions</b>				
"Seat Belt Unfastened" Detection				
Airbag				
Automatic re-locking				
Cadence variation by speed				
Central Locking Button Type				
Courtesy Light Timer				
De-Ice Function				
Engine type				
Flashing Buzzer				
Heated Rear Screen When Driving				
Illuminate Hazard Lamps Upon Impact				
Key block				
Originally Fitted Perimetric Protection				
Overspeed Alarm				
Programming of keys				
Radio Frequency Function				

Raid Function Authorisation By Diag
Rear Fog Lights
Rear Screen Wiper
Second Fitting Alarm
Timer Courtesy Light
Type of key
Vehicle Locked By Autolock When Driving Function
Verrou Logiciel (Software Lock)
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH trans 6_1 L35-522-08	✓	✓	✓	✓

Special Functions
"Seat Belt Unfastened" Detection
Airbag
Automatic re-locking
Central Locking Button Type
Courtesy Light Timer
De-Ice Function
Engine Type
Flashing Buzzer
Heated Rear Screen When Driving
Illuminate Hazard Lamps Upon Impact
Key Assignment
Key block
Originally Fitted Perimetric Protection
Overspeed Alarm
Radio Frequency Function
Raid Function Authorisation By Diag
Rear Fog Lights
Rear Screen Wiper
Second Fitting Alarm
Speed vibration cadence
Timer Courtesy Light
Type of key
Vehicle Locked By Autolock When Driving Function
Verrou Logiciel (Software Lock)
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH trans 6_1 L90 HDG Mercosur-522-08	✓	✓	✓	✓

Special Functions
"Seat Belt Unfastened" Detection
Airbag
Automatic re-locking
Cadence variation by speed
Central Locking Button Type
Courtesy Light Timer
De-Ice Function
Engine type
Flashing Buzzer
Heated Rear Screen When Driving
Illuminate Hazard Lamps Upon Impact
Key block
Key Programming
Originally Fitted Perimetric Protection
Overspeed Alarm
Radio Frequency Function
Raid Function Authorisation By Diag
Rear Fog Lights
Rear Screen Wiper
Second Fitting Alarm
Timer Courtesy Light
Type of key
Vehicle Locked By Autolock When Driving Function
Verrou Logiciel (Software Lock)
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH trans 6_1 L90 Mercosur-522-08	✓	✓	✓	✓

Special Functions
Erase Computer Memory

Flashing Buzzer				
Key Programming				
Uch Type				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH transv 6_1 L90 HDG -0522-09	✓	✓	✓	✓
<b>Special Functions</b>				
Flashing Buzzer				
Key programming				
Program Body Computer				
Type N5				
UCH Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH transv X90_OF_05-0000-0F	✓	✓	✓	✓
<b>Special Functions</b>				
"Seat Belt Unfastened" Detection				
Airbag				
Automatic re-locking				
Cadence variation by speed				
Central Locking Button Type				
Courtesy Light Timer				
De-Ice Function				
Engine Type				
Flashing Buzzer				
Heated Rear Screen When Driving				
Illuminate Hazard Lamps Upon Impact				
Key Assignment				
Key block				
Originally Fitted Perimetric Protection				
Overspeed Alarm				
Radio Frequency Function				
Raid Function Authorisation By Diag				
Rear Fog Lights				
Rear Screen Wiper				
SDO				
Second Fitting Alarm				
Signaling trailer				
Starter Relay Request				
Timer Courtesy Light				
Type of key				
Uch Type				
Vehicle Locked By Autolock When Driving Function				
Verrou Logiciel (Software Lock)				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X06 HdG Vdiag08	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic Relocking				
Flashing Buzzer				
Key reprogramming.				
UCH Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X06 X65 EXP Bas de Gamme (BIC)	✓	✓	✓	⊘
UCH X44 Vdiag 44 V01-0005-44	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning Type				
Alarm				
Automatic Lighting Function				
Automatic Locking When Driving				
Automatic Wiping Function				
Calibration				
Day Running Lights				
Deadlocking				
Engine Type				
External Temperature Sensor				
Front Fog Lights				
Gradual Switching On And Off Of Courtesy Light				

Hazard Warning Lights Illumination By Abs
Key Type
Memory Key Function
New Vehicle Storage Mode
One-Touch Electric Window(s) / Sunroof
Opening Elements Central Locking
Rain/Light Sensor
See-Me-Home Lighting
Temperature Display
Wiper Intermittent Speed Ring
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X61-0000-04	✓	✓	✓	✓

Special Functions
ALternator drive ratio
Automatic Relocking
Bodywork Type
Brake -pad wear test function
Day Running Lights
Deadlocking
Door lock diagnosis
External temperature display
Front Fog Lights
Fuel Cover
Hazard Warning Lights Illumination By Abs
Heated Rear Screen Configuration
Key Assignment
Key Control
Learned values in Energy management
One-Touch Electric Window(S)
Opening Type
Passenger Compartment Heating Resistor
Rain/Light Sensor
Rain/Luminosity Sensor Sensitivity
Rear Screen Wiper
See-Me-Home Lighting
Selective Opening Of Doors
Spinning motor information
Starter Switch Position
Type of climate
Type of light
UCH Configuration
Vehicle Type
Windscreen wiper/reverse gear
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH X61-0000-08-0000-08	✓	✓	✓	✓

Special Functions
Air Conditioning Type
ALternator drive ratio
Automatic Relocking
Bodywork Type
Brake -pad wear test function
Day Running Lights
Deadlocking
Door lock diagnosis
External temperature display
Front Fog Lights
Fuel Cover
Hazard Warning Lights Illumination By Abs
Heated Rear Screen Configuration
Key Control
Learned values in Energy management
One-Touch Electric Window(S)
Opening Type
Passenger Compartment Heating Resistor
Rain/Light Sensor
Rain/Luminosity Sensor Sensitivity
Rear Screen Wiper
See-Me-Home Lighting

Selective Opening Of Doors				
Spinning motor information				
Starter Switch Position				
Type of light				
UCH Configuration				
Vehicle Type				
Windscreen wiper/reverse gear				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH X65</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Automatic Relocking				
Clock				
Configure Instrument Panel Type				
Course ( Trajectory ) Control System				
Cruise Control / Speed Limiter Present				
Engine Type				
Gas Inj.				
GearBox Type				
Seat Belt Reminder Buzzer				
UCH Type				
Vehicle Speed Information				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH X65 EXPORT</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Automatic Relocking				
Bodywork type				
Ignition Keys Programming				
Illuminate Hazard Lamps Upon Impact				
Overspeed Function - Arabia				
Radio Frequency Function				
Rear Screen Demister				
Second Fitting Alarm				
Timer Courtesy Light				
UCH Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH X65 EXPORT VDIAG08</b>	✓	✓	✓	✓
<i>Special Functions</i>				
Automatic re-locking				
Bodywork type				
Key Programming				
Overspeed Function - Arabia				
Radio Frequency Function				
Rear Window Heater				
UCH Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH X65 MEXIQUE</b>	✓	✓	✓	✓
<i>Special Functions</i>				
2 Button Radio Frequency Key				
Automatic Relocking				
Bodywork type				
Ignition Keys Programming				
Illuminate Hazard Lamps Upon Impact				
Original Equipment Alarm				
Raid Function Authorisation by Diag				
Rear Screen Demister				
Timer Courtesy Light				
UCH Type				
With Radiofrequency (RF) Function				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
<b>UCH X65 MEXIQUE VDIAG 08</b>	✓	✓	✓	✓
<i>Special Functions</i>				
2 button radio frequency key				
Automatic re-locking				
Bodywork type				
Heated rear screen				
Illuminate Hazard Lamps Upon Impact				

Original Equipment Alarm				
Programming of keys				
Radio Frequency Function				
Raid Function Authorisation By Diag				
Timer Courtesy Light				
Uch Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X65 Mexique Vdiag08 type03	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic re-locking				
Illuminate Hazard Lamps Upon Impact				
Key Programming				
Raid Function Authorisation By Diag				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X65 VDIAG 0D (BIC)	✓	✓	✓	✓
<b>Special Functions</b>				
Additional Wiping After Washing				
Arabian Overspeed				
Automatic Relocking				
Automatic Re-Locking				
Daytime Running Lights				
Headlamp Washer				
Instrument Panel Type				
Luminosity Sensor				
Rain Sensor				
Second Fitting Alarm				
Timer Courtesy Light				
UCH Type				
Variable Windscreen Wiper Intermittent				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X65 VDIAG 5	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic Relocking				
Instrument Panel Type				
UCH Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X65 VDIAG 9 (BIC)	✓	✓	✓	✓
<b>Special Functions</b>				
Additional Wiping After Washing				
Arabian Overspeed				
Automatic Re-Locking				
Second Fitting Alarm				
Timer Courtesy Light				
UCH Type				
Variable Windscreen Wiper Intermittent				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X70ph2	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic re-locking				
Cruise Control / Speed Limiter				
Instrument Panel Type				
Key Programming				
UCH Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X76 Mux	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic re-locking				
Illuminate Hazard Lamps Upon Impact				
Key Programming				
Uch Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X76_OC Mux	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic re-locking				

Illuminate Hazard Lamps Upon Impact				
Instrument Panel Type				
Key Programming				
Uch Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X76_10 Mux	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic re-locking				
Illuminate Hazard Lamps Upon Impact				
Instrument Panel Type				
Key Programming				
Second Fitting Alarm				
Timer Courtesy Light				
Type of key				
Uch Type				
Wiper Blade Inverted				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X85-0000-48	✓	✓	✓	✓
<b>Special Functions</b>				
New Vehicle Storage Mode Deactivation				
Source Of Action Before Next - Last Action				
Source of Last Unlocking				
Source Of Next - Last Door Action				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X91-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Card testing				
Geographical Zone				
Light sensor sensitivity				
New Vehicle Storage Mode				
Programming the codes of the four valves				
Remote locking buzzer				
Scandinavia automatic day lights				
Second Fitting Alarm				
Selection of valve set				
Tyre Pressure Monitor Function				
Uch Type				
Windscreen Type				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X91-0000-08	✓	✓	✓	✓
<b>Special Functions</b>				
Card testing				
Light sensor sensitivity				
New Vehicle Storage Mode				
Programming the codes of the four valves				
Scandinavia automatic day lights				
Search For Valve Code				
Second Fitting Alarm				
Type of windscreen				
Tyre Pressure Monitor Function				
Uch Type				
Writing V.I.N.				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH X95-0000-04	✓	✓	✓	✓
<b>Special Functions</b>				
Card testing				
Day Running Lights				
Geographical Zone				
Programming the codes of the four valves				
Remote locking buzzer				
Scandinavia automatic day lights				
Second Fitting Alarm				
Type of windscreen				

Tyre Pressure Monitor Function				
Uch Type				
Valve's code reading				
Write of VIN				
<b>ECU</b>				
UCH_BCM_H45-0000-04				
Special Functions				
Alarm				
Anti-Theft Alarm Trigger S/W				
Automatic Lighting Function				
Card testing				
Day Running Lights				
Deadlocking				
Dongle				
Driving Type				
Engine type				
Gearbox type				
Geographical Zone				
Hands-Free Function				
Hazard Warning Lights Illumination By Abs				
Head Lamp Battery Saver Function				
Headlight Washers				
One-Touch Electric Window(S)				
Passenger Compartment Heating Resistor				
Programming Card				
Rain/Light Sensor				
Seat Belt Reminder Buzzer				
See-Me-Home Lighting				
Uch Type				
Unlocking Mode. Doors Hands Free				
Upload antisquashing electric crystals				
Writing V.I.N.				
<b>ECU</b>				
UCH_BDG -0522-09				
Special Functions				
"Seat Belt Unfastened" Detection				
Airbag				
Automatic re-locking				
Cadence variation by speed				
Central Locking Button Type				
Courtesy Light Timer				
De-Ice Function				
Engine type				
Flashing Buzzer				
Heated Rear Screen When Driving				
Illuminate Hazard Lamps Upon Impact				
Key Assignment				
Key block				
Key Code Registered				
Key Code Validated				
Originally Fitted Perimetric Protection				
Overspeed Alarm				
Radio Frequency Function				
Raid Function Authorisation By Diag				
Rear Fog Lights				
Rear Screen Wiper				
Second Fitting Alarm				
Signaling trailer				
Starter Relay Request				
Timer Courtesy Light				
Type of key				
Uch Type				
Vehicle Locked By Autolock When Driving Function				
Verrou Logiciel (Software Lock)				
Write Vin				
<b>ECU</b>				
UCH_X76G2005_VDiag18_V4.0				
Special Functions				
Clock				

Trouble Codes	Live Data	Actuators	Special Functions
✓	✓	✓	✓

Trouble Codes	Live Data	Actuators	Special Functions
✓	✓	✓	✓

Trouble Codes	Live Data	Actuators	Special Functions
✓	✓	✓	✓

Cruise Control / Speed Limiter
Day Running Lights
Engine Type
Fuel tank capacity
Gaz
Gearbox Type
Key Programming
Left Side Sliding Door
Maintenance Charge
Rear Screen Wiper
Seat Belt Reminder Buzzer
Selective Opening Of Doors
Timer Courtesy Light
Vehicle speed information
Vehicle Type
With Driver's One-Touch Window Control
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-0012-09	✓	✓	✓	✓

<b>Special Functions</b>
Aerial Test
Auto Locking Warning Sound
Automatic Closing Of Windows (By Card)
Card Frequency (in MHz)
Card Locking
Card Type
Check Cards
Daytime Running Lights
Deadlocking
Driving Type
Electric Child Safety
External Follow Lighting
Following Tyre Change
Front Left Wheel Learning
Front Right Wheel Learning
GearBox Type
Hands Free Locking
Hands-Free Function
Hands-Free Start-Up
Hazard Warning Lights Illumination by ABS
Headlight Washers
Inhibition of Selective Door Opening
Left Rear Wheel Learning
Light sensor sensitivity
Lights Automatic Illumination
Memorising Driver's Seat Position
Overspeed Function - Arabia
Programming Card
Rain/Light Sensor
Right Rear Wheel Learning
SELECT WHEEL SET
Selective Opening of Doors
Sunroof
Type Of Power Steering
Tyre Pressure Monitor Function
Vehicle Family
Vehicle Type

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-0031-04	✓	✓	✓	✓

<b>Special Functions</b>
Aerial Test
Auto Locking Warning Sound
Automatic Closing Of Windows (By Card)
Automatic Locking When Driving
Check Cards
Day Running Lights
Deadlocking
Discharge Lamp
Driving Type
Electric Child Safety

Enter Recommended Pressures
Following Tyre Change
Front left-hand wheel valve code
Front right-hand wheel valve code
Gearbox Type
Hands Free Locking
Hands-Free Function
Hands-Free Start-Up
Hands-Free System Test
Hazard Warning Lights Illumination By Abs
Headlight Washers
Inhibition of Selective Door Opening
Light sensor sensitivity
Lights Automatic Illumination
Memorising Driver's Seat Position
Programming Card
Programming the codes of the four valves
Rain/Light Sensor
Rear left-hand wheel valve code
Rear right-hand wheel valve code
See-Me-Home Lighting
Selective Opening Of Doors
Sunroof
Timer Courtesy Light
Type Of Power Steering
Tyre Pressure Monitor Function
Uch Connections Test -> Card Reader
Valve set
Valve Set Selection
Vehicle Family
Vehicle Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-0031-15	✓	✓	✓	✓

Special Functions
Aerial Test
Auto Locking Warning Sound
Automatic Closing Of Windows (By Card)
Automatic Locking When Driving
Check Cards
Day Running Lights
Deadlocking
Discharge Lamp
Driving Type
Electric Child Safety
Enter Recommended Pressures
Following Tyre Change
Front left-hand wheel valve code
Front right-hand wheel valve code
Gearbox Type
Hands Free Locking
Hands-Free Function
Hands-Free Start-Up
Hands-Free System Test
Hazard Warning Lights Illumination By Abs
Headlight Washers
Inhibition of Selective Door Opening
Light sensor sensitivity
Lights Automatic Illumination
Memorising Driver's Seat Position
Programming Card
Programming the codes of the four valves
Rain/Light Sensor
RAIN/LUMINOSITY SENSOR TYPE
Rear left-hand wheel valve code
Rear right-hand wheel valve code
See-Me-Home Lighting
Selective Opening Of Doors
Sunroof
Timer Courtesy Light

Type Of Power Steering			
Tyre Pressure Monitor Function			
Uch Connections Test -> Card Reader			
Valve set			
Valve Set Selection			
Vehicle Family			
Vehicle Type			
Write Vin			
<b>ECU</b>			
<b>UCH-09-44</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓
<b>Special Functions</b>			
Air Conditioning Type			
Automatic Relocking			
Buzzer Activation Request			
Childproof Lock			
Daytime Running Lights			
Deadlocking			
Driving Type			
Engine Type			
External Follow Lighting			
Front Fog Lamp			
GearBox Type			
Hands-Free Function			
Hazard Warning Lights Illumination by ABS			
Heating Resistor Type			
Illuminated Hazard Lamps Upon Impact			
Light Sensor			
Pax System Type Tyre			
Programming Card			
Rain Sensor			
Rear Wiper Park Position Management			
Selective Opening of Doors			
Tyre Pressure Monitoring			
Vehicle Type			
Windscreen Type			
<b>ECU</b>			
<b>UCH-85_D9-50</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓
<b>Special Functions</b>			
Antennes Acces Arriere			
Childproof Lock			
Deadlocking			
Discharge Lamp			
Driving Type			
External Temperature Sensor			
Front Fog Lights			
Gearbox Type			
Hazard Warning Lights Illumination By Abs			
One-Touch Electric Window(s) / Sunroof			
UCH Type			
Windscreen Type			
Write of VIN			
<b>ECU</b>			
<b>UCH-90-04</b>			
<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
✓	✓	✓	✓
<b>Special Functions</b>			
Auto Locking Warning Sound			
Automatic Closing Of Windows (By Card)			
Automatic Locking When Driving			
Automatic Seat Recall			
Card Locking			
Card Reminder Warning			
Change in Triggering Limit			
Check Cards			
Day Running Lights			
Deadlocking			
Door Unlocking Mode			
Electric Child Safety			
Enter Recommended Pressures			
Following Tyre Change			
Gearbox Type			

Hands Free Locking
Hands-Free Function
Hazard Warning Lights Illumination By Abs
Interior lighting
Lights Automatic Illumination
Lock Latch Locking
Memorising Driver's Seat Position
Overspeed Function - Arabia
Power-Assisted Steering Program
Programming Card
Programming the codes of the four valves
Rain detector
See-Me-Home Lighting
Selection of valve set
Timer Courtesy Light
Type of driving
Type Of Power Steering
Tyre Pressure Monitor Function
Uch Connections Test -> Card Reader
Unlocking Mode. Doors Hands Free
Voice Synthesiser
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-90-0C	✓	✓	✓	✓

Special Functions
Arabian Overspeed
Auto Locking Warning Sound
Automatic Closing of Windows
Automatic Locking When Driving
Automatic Seat Recall
Card Locking
Card Reminder Warning
Daytime Running Lights
Deadlocking
Door Unlocking Mode
Driving Type
Electric Child Safety
External Follow Lighting
Front LH Valve Code, Summer Tyres
Front LH Valve Code, Winter Tyre
Front RH Valve Code, Summer Tyres
Front RH Valve Code, Winter Tyres
GearBox Type
Hands Free Locking
Hands-Free Function
Hazard Warning Lights Illumination by ABS
Interior Light
Lights Automatic Illumination
Memorising Driver's Seat Position
Power Assisted Steering
Power Steering
Programming Card
Programming the Codes of the Four Valves
Rain Sensor
Rear LH Valve Code, Summer Tyres
Rear LH Valve Code, Winter Tyres
Rear RH Valve Code, Summer Tyres
Rear RH Valve Code, Winter Tyres
Timer Courtesy Light
Tyre Pressure Monitoring
Unlocking Mode Doors Hands Free
Valve
Valve Set Recognised
Voice Synthesizer

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-B400-48	✓	✓	✓	✓

Special Functions
Automatic re-locking
Enter Recommended Pressures
Front Fog Lights

Hazard Warning Lights Illumination By Abs				
Programming Card				
Programming the codes of the four valves				
See-Me-Home Lighting				
Uch Type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH-B450-4C	✓	✓	✓	✓
<b>Special Functions</b>				
Automatic Relocking				
Childproof Lock				
Enter Recommended Pressures				
External Follow Lighting				
Front Fog Lights				
Front Left wheel (AVG) Code of Summer Set				
Front Left wheel (AVG) Code of Winter Set				
Front Right wheel (AVD) Code of Summer Set				
Front Right wheel (AVD) Code of Winter Set				
Hazard Warning Lights Illumination by ABS				
Programming Card				
Programming the Codes of the Four Valves				
Rear Left wheel (ARG) Code of Summer Set				
Rear Left wheel (ARG) Code of Winter Set				
Rear Right wheel (ARD) Code of Summer Set				
Rear Right wheel (ARD) Code of Winter Set				
Valve Set Recognised				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH-B500-4D	✓	✓	✓	✓
<b>Special Functions</b>				
Air Conditioning Type				
Automatic re-locking				
Childproof Lock				
Daytime Running Lights				
Deadlocking				
Driving Type				
Engine Type				
External temperature sensor circuit				
Front Fog Lights				
GearBox Type				
Hands Free				
Hazard Warning Lights Illumination By Abs				
Heating Resistor Type				
Illuminated Hazard Lamps Upon Impact				
Light Sensor				
One Touch Electric Windows				
Originally Fitted Permetric Protection				
Pax System Type Tyre				
Programming Card				
Programming the Codes of the Four Valves				
Rain Sensor				
Rear Wiper Park Position Management				
See-Me-Home Lighting				
Selective Opening of Doors				
Tyre Pressure Monitoring				
Valet Card Function				
Vehicle Type				
Windscreen Type				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UCH-BC_D9-50	✓	✓	✓	✓
<b>Special Functions</b>				
"Valet" Card Function				
Antennes Acces Arriere				
Card testing				
Childproof Lock				
Day Running Lights				
Deadlocking				
Engine Type				
Enter Recommended Pressures				

External Temperature Sensor
Fault reading
Feed Level Requested
Front Fog Lights
Gearbox type
Hands-Free Function
Hazard Warning Lights Illumination By Abs
Heating Resistor Type
New Vehicle Storage Mode
New Vehicle Storage Mode Deactivation
One-Touch Electric Window(s) / Sunroof
Originally Fitted Perimetric Protection
Pax System Type Tyre
Programming Card
Programming the codes of the four valves
Rain/Light Sensor
Rear Screen Wiper
Selective Opening Of Doors
Type of climate
Type of driving
Type of windscreen
Tyre Pressure Monitor Function
Uch Type
Upc Comp. Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-J_D9-50	✓	✓	✓	✓

Special Functions
Antennes Acces Arriere
Deadlocking
Driving Type
Engine Type
Enter Recommended Pressures
External Temperature Sensor
Front Fog Lights
Front Left wheel (AVG) Code of Summer Set
Front Left wheel (AVG) Code of Winter Set
Front Right wheel (AVD) Code of Summer Set
Front Right wheel (AVD) Code of Winter Set
Gearbox Type
Hazard Warning Lights Illumination By Abs
New Vehicle Storage Mode Deactivation
Programming Card
Programming the codes of the four valves
Rear Left wheel (ARG) Code of Summer Set
Rear Left wheel (ARG) Code of Winter Set
Rear Right wheel (ARD) Code of Summer Set
Rear Right wheel (ARD) Code of Winter Set
Rear Screen Wiper
Upc Comp. Type
Valve Set Recognised
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-J400-48	✓	✓	✓	✓

Special Functions
Air conditioning type
Automatic re-locking
Childproof Lock
Day Running Lights
Deadlocking
Engine Type
Enter Recommended Pressures
Front Fog Lights
Gearbox type
Hands-Free Function
Hazard Warning Lights Illumination By Abs
Heating Resistor Type
Illuminate Hazard Lamps Upon Impact
Light Sensor
Pax System Type Tyre

Programming Card
Programming the codes of the four valves
Rain detector
Rear Wiper Park Position Management
See-Me-Home Lighting
Selective Opening Of Doors
Type of driving
Tyre Pressure Monitor Function
Uch Type
Vehicle Type
Windscreen Type
Write Vin

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-J450-4C	✓	✓	✓	✓

Special Functions
Automatic Relocking
Childproof Lock
Enter Recommended Pressures
External Follow Lighting
Front Fog Lights
Front Left wheel (AVG) Code of Summer Set
Front Left wheel (AVG) Code of Winter Set
Front Right wheel (AVD) Code of Summer Set
Front Right wheel (AVD) Code of Winter Set
Hazard Warning Lights Illumination By Abs
Programming Card
Programming the Codes of the Four Valves
Rear Left wheel (ARG) Code of Summer Set
Rear Left wheel (ARG) Code of Winter Set
Rear Right wheel (ARD) Code of Summer Set
Rear Right wheel (ARD) Code of Winter Set
Valve Set Recognised
Write of VIN

ECU	Trouble Codes	Live Data	Actuators	Special Functions
UCH-J500-4D	✓	✓	✓	✓

Special Functions
"Valet" Card Function
Air Conditioning Type
Automatic re-locking
Card testing
Childproof Lock
Day Running Lights
Deadlocking
Driving Type
Engine Type
Enter Recommended Pressures
External Temperature Sensor
Front Fog Lights
Gearbox Type
Hands-Free Function
Hazard Warning Lights Illumination By Abs
Heating Resistor Type
Illuminate Hazard Lamps Upon Impact
Light Sensor
One-Touch Electric Window(S)
Originally Fitted Perimetric Protection
Pax System Type Tyre
Programming Card
Programming the codes of the four valves
Rain detector
Rear Wiper Park Position Management
See-Me-Home Lighting
Selective Opening Of Doors
Tyre Pressure Monitor Function
Uch Type
Vehicle Type
VIN Code
Windscreen Type

ECU	Trouble Codes	Live Data	Actuators	Special Functions
BIC-VP-VU-0321-04-0321-04	✓	✓	✓	✓
Special Functions				
Ecu Memory				
Vehicle Type				
Write Vin				
<b>MULTIMEDIA CONNECTION</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
CBOX_X85-00-04	✓	✓	⊘	✓
Special Functions				
System configuration				
Write Date Of Last After Sales Operation				
Writing V.I.N.				
<b>NAVIGATION</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
NAV 4R-0000-24	✓	✓	✓	✓
Special Functions				
CD player				
ECU configuration				
Type of vehicle				
Write Vin				
<b>NETWORK INFORMATION</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
NETWORK ANALYSIS (CAN)	👤	⊘	⊘	✓
Special Functions				
Get network information				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
NETWORK ANALYSIS (KWP)	👤	⊘	⊘	✓
Special Functions				
Get network information				
<b>PARKING ASSISTANCE</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING AID-0000-0C	✓	✓	⊘	✓
Special Functions				
Buzzer Volume				
Front Buzzer Volume				
Front Tone Setting				
Tone Adjustment				
Vehicle Identification				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING ASSISTANCE -000-04	✓	✓	⊘	✓
Special Functions				
Buzzer Volume				
Tone Adjustment				
Vehicle Identification				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING ASSISTANCE X44-0000-04	✓	✓	⊘	✓
Special Functions				
Buzzer Volume				
Tone Adjustment				
Vehicle ID				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING ASSISTANCE x74 AAP	✓	✓	✓	✓
Special Functions				
Buzzer Volume				
Tono Adjustment				
Vehicle Type				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING ASSISTANCE X83 Ph2-0000-04	✓	✓	⊘	✓

<b>Special Functions</b>				
Buzzer Volume				
Tone Adjustment				
Vehicle Identification				
Write Vin				
<b>ECU</b>				
PARKING ASSISTANCE-0000-04				
PARKING ASSISTANCE-0000-08				
<b>Special Functions</b>				
Buzzer Volume				
Caravan Towing Distance				
Tone Adjustment				
Vehicle ID				
Write Vin				
<b>PARKING BRAKE</b>				
<b>ECU</b>				
FPA X91-0000-04				
<b>Special Functions</b>				
Activation of assisted clamping stop				
Write Vin				
<b>ECU</b>				
FPA X95-0000-04				
FREIN DE PARKING Star 12-0102-0D				
<b>Special Functions</b>				
Computer Calibration And Operation				
ECU replacement				
Slope Initialisation				
Vehicle Configuration				
Write of VIN				
<b>ECU</b>				
FREIN DE PARKING-8511-01				
<b>Special Functions</b>				
Computer Calibration And Operation				
Save / Write Clutch Pedal Programming				
Slope Initialisation				
Vehicle Configuration				
Write of VIN				
<b>ECU</b>				
FREIN DE PARKING-B350-08				
<b>Special Functions</b>				
Computer Calibration And Operation				
Save Clutch Pedal Programming				
Slope Initialisation				
Vehicle Configuration				
Write of VIN				
<b>ECU</b>				
PARKING BRAKE B351-08				
<b>Special Functions</b>				
Computer Calibration And Operation				
Save / Write Clutch Pedal Programming				
Slope Initialisation				
Vehicle Configuration				
Write of VIN				
<b>ECU</b>				
PARKING BRAKE J84-B300-04				
<b>Special Functions</b>				
Computer Calibration And Operation				
ECU replacement				
Engine Type				
GearBox Type				
Slope Initialisation				
Steering Wheel Position				
Vehicle Configuration				
Vehicle Type				
Write of VIN				

ECU	Trouble Codes	Live Data	Actuators	Special Functions
PARKING BRAKE-0102-0C	✓	✓	✓	✓
<i>Special Functions</i>				
Computer Calibration And Operation				
Save / Write Clutch Pedal Programming				
Slope Initialisation				
Vehicle configuration				
Write Vin				
<b>PASSENGER DOOR MODULE</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
RDCM X91 -0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
Frost management mode				
Writing V.I.N.				
<b>POWER STEERING</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
D.A. Electrique-000-04	✓	✓	⊘	✓
<i>Special Functions</i>				
Computer Calibration				
Steering Wheel Angle Sensor Programming				
Write Date Of After Sales Operation				
Write Vin				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
D.A. Electrique-0S02-08	✓	✓	⊘	✓
<i>Special Functions</i>				
Computer Calibration				
PostSale Repair Date Modification				
Steering Wheel Angle Sensor Programming				
Steering Wheel Sensor Programming				
Write of VIN				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
D.A. Electrique-1500-10	✓	✓	⊘	✓
<i>Special Functions</i>				
Computer Calibration				
Electrical Damper At Stop				
Pulling Correction				
Steering Wheel Sensor Programming				
Tyres				
Write Date Of After Sales Operation				
Writing V.I.N.				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
D.A.E X61-00ED-05	✓	✓	⊘	✓
<i>Special Functions</i>				
Mode Number				
Steering Wheel Angle Sensor Programming				
Write Date Of After Sales Operation				
Write Vin				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DAE_X44_V1_0000_04_A-0000-04	✓	✓	⊘	✓
<i>Special Functions</i>				
Mode Number				
Type Of Power Steering				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DAE_X95-0000-04	✓	✓	✓	✓
<i>Special Functions</i>				
Steering Wheel Angle Sensor Programming				
Write Vin				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
DAE-0000-14	✓	✓	⊘	✓
<i>Special Functions</i>				
Computer Calibration				
Electrical Damper At Stop				
Pulling Correction				
Steering Wheel Sensor Programming				

Tyres				
Write Date Of After Sales Operation				
Write Vin				
ECU				
DAE-0S02-06	✔	✔	✔	✔
Special Functions				
Computer Calibration				
Steering Wheel Sensor Programming				
Write Date Of After Sales Operation				
Write of VIN				
ECU				
DAV_daex84_0002_04_A	✔	✔	⊘	✔
Special Functions				
Computer Calibration				
Steering Wheel Angle Sensor Programming				
Write Date Of After Sales Operation				
Write of VIN				
ECU				
DAV_EPS_H45-0000-04	✔	✔	⊘	⊘
ELECTRIC PASS (CLIO III)	✔	✔	⊘	✔
Special Functions				
Steering Wheel Sensor Programming				
ECU				
ELECTRIC PASS-9112-08	✔	✔	⊘	✔
Special Functions				
Steering Wheel Sensor Programming				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU				
GEP X91-0000-04	✔	✔	⊘	✔
Special Functions				
Write Vin				
ECU				
GEPDA H79-A040-08	✔	✔	⊘	✔
Special Functions				
Computer Calibration				
Write Date Of After Sales Operation				
Write Vin				
ECU				
GEPDA L35 vdiag 04-A040-04	✔	✔	⊘	✔
Special Functions				
Write Date Of After Sales Operation				
Write Vin				
ECU				
GEPDA L90 vdiag 04_B2-A040-04	✔	✔	⊘	✔
Special Functions				
Computer Calibration				
Write Date Of Last After Sales Operation				
Write of VIN				
ECU				
GEPDA_L90_VDIAG_08_B2-00-08	✔	✔	⊘	✔
Special Functions				
Computer Calibration				
Write Date Of After Sales Operation				
Write Vin				
ECU				
GEPDA-A040-04	✔	✔	⊘	✔
Special Functions				
Computer Calibration				
Write Date Of After Sales Operation				
Write Vin				
ECU				
POWER STEERING X56	✔	✔	✔	👤

ECU	Trouble Codes	Live Data	Actuators	Special Functions
POWER STEERING X56 F2	✓	✓	⊘	⊘
POWER STEERING X65 V 1.6	✓	✓	✓	✓
Special Functions				
Computer Calibration				
PostSale Repair Date Modification				
<b>RADIO</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
LPN-VP-VU-0002-C4-0002-C4	✓	✓	✓	✓
Special Functions				
CD changer and auxiliary input				
Computer Calibration And Operation				
Distance Units				
Test Parameters				
Type of vehicle				
Vehicle Configuration				
Write Date Of After Sales Operation				
Write Vin				
<b>SUNROOF</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
ELECTRIC ROOF COMPUTER UCT E84	✓	✓	✓	✓
Special Functions				
Side				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
HOOD CONTROL X64	⚠	✓	✓	✓
Special Functions				
Fast Erase Fault				
FAULT CODE READING				
<b>TIRE PRESSURE CONTROL</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
TIRE PRESSURE CONTROL M2S v9.0 X64 phase 3	✓	✓	✓	✓
Special Functions				
Change in Triggering Limit				
Enter Recommended Pressures				
Following Tyre Change				
Front Left Wheel Learning				
Front Right Wheel Learning				
Left Rear Wheel Learning				
Right Rear Wheel Learning				
Selection of valve set				
Type of vehicle				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
TYRE CONTROL SSPP J77-X85	✓	✓	⊘	✓
Special Functions				
Front Left Wheel Valve Information				
Front Right Wheel Valve Information				
Rear Left Wheel Valve Information				
Rear Right Wheel Valve Information				
Write of VIN				
<b>TRACKING</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
SVT-V1-04	✓	✓	⊘	✓
Special Functions				
Alarm				
Extern GPS Aerial				
Temporized Battery +				
Write Vin				
<b>UPC</b>				
ECU	Trouble Codes	Live Data	Actuators	Special Functions
UPC (CLIO III)	✓	✓	✓	✓
Special Functions				
Alternator type				
Engine Type				
Starting Conditions Satisfied				

Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UPC (MEGANE II)	✓	✓	✓	✓
Special Functions				
Alternator				
Alternator type				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UPC (MODUS)	✓	✓	✓	✓
Special Functions				
Alternator				
Engine Type				
Starting Conditions Satisfied				
Starting Mode				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UPC X91-0000-04	✓	✓	✓	✓
Special Functions				
Automatic Configuration				
Computer Initialisation				
Internal Protection Rearm				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
UPC_IPDM_H45-0000-04	✓	✓	✓	⊘
UPCJR95_L38-0000-05	✓	✓	✓	✓
Special Functions				
Computer Initialisation				
Internal Protection Rearm				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
USM JR95 X38 V09-0000-09	✓	✓	✓	✓
Special Functions				
Internal Protection Rearm				
Write Vin				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
USM_84 Phase_2 C5_4 v1	✓	✓	✓	✓
Special Functions				
Alternator Type				
Configuration				
Front Fog Lights				
Gearbox Type				
Headlight Washers				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
USM_84 Phase_2 C5_4.2 v1-C54.2-4C	✓	✓	✓	✓
Special Functions				
Write of VIN				
<b>ECU</b>	<b>Trouble Codes</b>	<b>Live Data</b>	<b>Actuators</b>	<b>Special Functions</b>
USM_X61_C5_7_V1_3-00C5-50	✓	✓	✓	✓
Special Functions				
Climatization				
Engine Suffix				
Engine Type				
Front Fog Lights				
Fuel type				
Gas Equipment				
Gearbox type				
Rear Screen De-Icing				
Write Date Of Last After Sales Operation				
Write of VIN				